

Freescale Semiconductor

Application Note

Document Number: AN3927 Rev. 1, 02/2012

Freescale S08 USB Mass Storage Device Bootloader

by: Derek Snell Field Applications Engineer

1 Introduction

Freescale offers a broad selection of microcontrollers with USB. Designing a product with USB allows for an easy interface to do field updates of the product's firmware. This application note describes a mass storage device (MSD) USB bootloader written to work with several Freescale USB families. A device with this bootloader is connected to a host computer, and the bootloader enumerates as a new drive. The new firmware is copied onto this drive, and the device reprograms itself.

Freescale does offer other bootloaders. For example, the application note titled *USB Bootloader for the MC9S08JM60* (document AN3561) is a different USB bootloader written for the Flexis JM family. This MSD bootloader is offered as another option with these advantages:

• It does not require a driver to be installed on the host

Contents

1	Introduction
2	Functional Description
3	CodeWarrior Project Structure9
4	Using the Bootloader 16
5	Troubleshooting
6	Conclusion
Appe	endix A mcf5222x_vectors.s for the Coldfire V2 CMX Exam-
ple	
Appe	endix B LCF File for ColdFire V2 CMX Example 47
Appe	endix C hid_main.c for ColdFire V2 CMX Example 51
Appe	endix D usr_entry_V2.c for ColdFire V2 CMX Example . 54
Appe	endix E LCF File for ColdFire V1 CMX Example 57
Appe	endix F hid_main.c for the ColdFire V1 CMX Example 61
Appe	endix G PRM File for the MC9S08 CMX Example 66
Appe	endix H hid_main.c for the MC9S08 CMX Example 69



© Freescale Semiconductor, Inc., 2009, 2012. All rights reserved.

NP

Functional Description

- It does not require an application to run on the host
- Any user can use it with a little training. The only action required is to copy a file onto a drive.
- It can be used with many different host operating systems. It requires no host software or driver
- The bootloader and application are integrated in one project. The device needs to be programmed only once in production. Separate programming steps for the bootloader and application are not required.

This bootloader was specifically written for several families of Freescale microcontrollers that share similar USB peripherals. These families include, but are not limited to the following: The Flexis JM family MC9S08JM and MCF51JM, MC9S08JS, and the ColdFire MCF522xx parts with USB. This bootloader must work on all of these devices with few changes, examples were written and tested on the following:

Tested Freescale microcontrollers:

- MCF52259—32-bit ColdFire V2 with USB, Ethernet, CAN, and external bus
- MCF51JM128—32-bit ColdFire V1 with USB, part of the Flexis JM Family
- MC9S08JM60—8-bit S08 with USB, part of the Flexis JM Family

Tested development boards:

- M52259DEMO—Low-Cost development board for MCF5225x family
- DEMOJM—Low-Cost development board for Flexis JM family

Tested operating systems:

- Windows XP Pro with Service Pack 2
- Windows Vista business for 32-bit with Service Pack 1
- Fedora 8 with Linux kernel 2.6.26

2 Functional Description

2.1 General Overview

The bootloader is integrated with an application that performs the product's main functions. At reset, the bootloader is executed and does some simple checks to see if the application should start, or if the bootloader should start. If it enters bootloader mode, it uses USB to enumerate with the host computer. During this enumeration process, the device declares itself as an MSD. The host then creates a new drive in the system. You can then copy an S-record file onto the drive, and the device re-programs itself.

S-record files are common ASCII files used to specify the program data stored in devices. Freescale's software tool chain called CodeWarrior generates S-record files automatically when projects are compiled. These files have the extension .S19 and are referred to as S19 files.

After the S19 file has been transferred to the device and the device re-programs itself, the device re-enumerates with the host. A file is displayed in the drive that represents the status of the bootloader operation.



Functional Description



Figure 1. Bootloader functional flow chart

2.2 Bootloader Mode vs. Application Mode

The bootloader starts executing immediately after reset and determines what mode is entered. It is important for the bootloader to be in control after reset to allow the bootloader to run if the application is not present, has been erased, or has become corrupted. Normally, the bootloader attempts to enter application mode. It does this through a user entry vector. The user entry vector is a jump vector at a specified absolute address that jumps to the entry point of the application. This user entry vector is used to prevent cross-calling (see Section 4.1, "Prevent Cross-Calling," on page 16). The address of the application entry point might change with each compile. But the address of the user entry vector is always the same. Therefore, the bootloader is programmed to always jump to the absolute address of the user entry vector that then jumps to the application entry point.



Functional Description

Before entering application mode, the bootloader performs some simple checks to ensure the application is present. It checks that the user entry vector includes the JUMP op-code. It also checks that the jump address in that vector is not erased. If the user entry vector is a good jump vector, then the bootloader jumps to the application. If the vector is not good, then the bootloader loads to allow an application update.

The bootloader mode can also be forced during a reset. The included examples monitor a button, and if the button is pressed during reset the bootloader mode is entered regardless of the user entry vector status. The button used to enter this mode depends on the development board; see Section 4.2, "Using Bootloader on the Demo Board," on page 18 for the specific button. Many applications need to change the method used to force bootloader mode. This can be executed by modifying the usr_entry_xx.c file.

2.3 USB Enumeration

After the bootloader enters bootloader mode, it enables the USB peripheral to communicate with the host computer. This starts the USB enumeration process. For more details on enumeration, please refer to application note titled *USB and Using the CMX USB Stack* (document AN3492). The USB stack used by this bootloader is Freescale's USB Mini-Stack, which has a very small memory footprint. The device sends the host descriptors that declare it as a mass storage device. The host loads the device as a new drive, and uses bulk transfers to communicate with the device. These bulk transfers send SCSI commands to talk to what the host thinks is a removable storage drive.

2.4 Pseudo-FAT

After the host thinks the bootloader is a storage drive, it attempts to read the file allocation table (FAT) of the drive, and reads the drive's contents. The bootloader responds to these queries with information that looks like a 1 GB drive. The drive has the volume name of BOOTLOADER. It looks like it has no directories and has a file called READY.TXT in the root directory. The bootloader does not use a true file system, and is only capable of acting like a drive to the host. It also accepts files to be written to the drive to transfer the S19 file. However, because the bootloader is only a Pseudo-FAT system, it does not update the FAT while the host attempts to change it. The FAT is always fixed, and the only change is the name of the file in the root directory that specifies the status of the bootloader. When the host writes data to the drive, the bootloader ignores all data that is not written to the root directory of the drive. When file data is written to the root directory, the bootloader assumes it is an S19 file. It starts the S-record parser to get the new firmware update. Only one file can be transferred to the drive after reset. After a file is transferred, the bootloader needs to restart to accept another file.

2.5 S-Record Parser

The bootloader includes an S-record parser to allow raw S19 files to be sent to the bootloader. After a file has been transferred to the bootloader, it assumes it is an S19 file and starts to parse it. Each S-record is checked to ensure it is a valid S-record with a correct checksum. The parser compares the S-record address to check if it is in the application space. It checks all S-records, but ignores the data in S-records outside of the application flash address range. After the first application S-record is successfully checked, the parser erases the entire application flash. Then, it programs each S-record after it is checked. The parser looks for a final S-record of type 7, 8, or 9 to know that the file transfer is complete. If the final S-record





is received, all S-records were valid, and all flash operations were successful, the parser returns with success. If at any point an S-record was invalid, the parser returns with the address of the invalid S-record.

NOTE

This parser can also be used by other bootloaders or applications that do not use USB. If a different communication is desired, the function GetUSBchar() can be replaced with a new function that receives a character through a different interface, like a UART or CAN.

2.6 Re-Enumeration

After the S-record parser finishes, the device re-enumerates with the host to update the status file on the drive. The status files are discussed in Section 2.7, "Bootloader Status," on page 5. Within the host computer, the drive disappears as the device drops off the USB bus. After a few seconds, the device re-enumerates and the drive re-appears. You can read the status file on the drive to see the status of the bootloader.

The bootloader re-enumerates because some host operating systems cache the file data on the storage drive, and do not refresh. For example, if using Fedora 8 with this bootloader, the operating system (OS) does not write the file to the device until the drive is unmounted. After unmounting, the device receives the S19 file, updates the firmware, and then re-enumerates to display the status. In Windows XP and Vista, the OS caches the drives FAT without re-reading it, and the status file is not updated. Re-enumeration forces the host to re-read the FAT and display the bootloader status file.

2.7 Bootloader Status

The bootloader uses the file system drive in the host computer to display the status. With this method, the bootloader status can always be seen regardless of the display or LEDs available on the device's hardware. In the case of an S-record error, the address of the error is also displayed. The status is displayed in the filename in the root directory of the drive. These files are empty and have no data. Before a file is transferred to the bootloader, the user must check the status file is READY.TXT. After the file transfer is complete, and the bootloader re-enumerates, the user must check the status file to see if it was a success. The status filenames are listed below:

- READY.TXT—Shows the bootloader is ready to receive an S19 file
- SUCCESS.TXT—Shows the bootloader completed a firmware update successfully.
- FFAILED.TXT—Shows the bootloader had a flash erase or program error. This error is triggered if the flash erase or program routine returns with an error. This error is usually triggered because the flash clock is not at the appropriate frequency, or an invalid address is used. If the address is not a flash address or is protected, this error occurs. To diagnose, place a breakpoint where this error is generated in ParseS19.c and run the debugger to find where the error occurs.
- SFxxxxx.TXT—Shows the bootloader S-record parser found an error in an S-record. The parser checks each S-record to ensure it has a valid format and the checksum matches. If not, this error is generated. This error can also occur if the S-record specifies an invalid address. The address of the improper S-record appears in the filename. For example, if the S-record for address 0x1234 was



Functional Description

invalid, the status filename would be SF001234.TXT. If this error occurs, check the S-record for proper format, checksum, and address.

• STARTED.TXT—Shows a file has been received with data for the root directory and the S-record parser has started. Normally, this status should not be visible to the user because the drive only re-enumerates after a success or failure. If seen, debug the bootloader to learn why.

2.8 Flash Protection

A bootloader must always be protected from erasing itself or getting corrupted. With this protection enabled, the worst case scenario during a botched firmware update is that the application is erased or corrupted, but the bootloader is still in tact. The bootloader can then run again and re-load the new application.

This bootloader uses Freescale's flash protection features. Depending on the part used, the microcontroller has a non-volatile register that specifies what flash sectors are protected. The bootloader is stored in these protected sectors and the application is stored in the unprotected sectors. These non-volatile register settings are part of the bootloader and cannot be changed by the application. In addition, this flash protection also protects the reset and interrupt vectors from being changed by the application.

Here is a list of the flash protection registers by the core, the sectors protected, and the bootloader file that loads these registers. Refer to Table 4 to see how this affects the flash memory usage.

- ColdFire V2—Register CFMPROT is set to 0x1 and protects the flash address range 0x0 to 0x3FFF. This register is set in file mcf5225x_vectors.s.
- ColdFire V1—Register NVPROT is set to 0xF7, and protects the flash address range 0x0 to 0x1FFF. This register is set in the file Bootloader_V1.c.
- MC9S08—Register NVPROT is set to 0xEA, and protects the flash address range 0xEC00 to 0xFFFF. This register is set in the file Bootloader_S08.c.

NOTE

If the bootloader is modified, these flash protected sectors can be increased or decreased to properly protect the bootloader. If the address range is changed, change the above registers, and also change the memory map in the linker file and in Bootloader_xx.h.

2.9 Interrupt Vector Table Re-Direction

The application cannot change the default interrupt vector table of the microcontroller because that flash memory is protected. Therefore, the bootloader re-directs the interrupt vectors into the application space that allows the application to update its interrupt vectors. Because the bootloader re-directs the interrupt vectors, this also means the bootloader cannot use interrupts. The bootloader is implemented by polling the USB interrupt flag to see when a packet was sent or received.

The bootloader was written with each core using a different method for interrupt re-direction, and is further explained with examples in Section 4.3, "Creating a New Project with the Bootloader," on page 20.



2.10 Stack and RAM Usage

The bootloader interacts with the application only when it starts the application by jumping to the user entry vector. The application never cross-calls functions into the bootloader. Therefore, the bootloader and application do not need to have separate RAM memory. They can both use the same physical RAM. From the application's perspective, the bootloader uses no RAM, this is because the application has access to the entire RAM in the device. The linker files are setup to share the physical RAM between the bootloader and the application. They also share the stack, so the location and size of the stack are the same for both the bootloader and application.

2.11 Bootloader Memory Maps

The following sections show the memory maps for the three different device examples. The memory map for both the bootloader and application are shown to see how the RAM overlaps. Notice the application has access to all RAM and overlaps the bootloader RAM. All other memory sections are identical between the two.

2.11.1 ColdFire V2 Bootloader Memory Maps

Addresses	Bootloader	Application
0x0000_0000 to 0x0000_03FF	Interrupt and exception vectors	Interrupt and exception vectors
0x0000_0400 to 0x0000_0417	Flash protection and security registers	Flash protection and security registers
0x0000_0420 to 0x0000_3FFF	Bootloader flash (15 kB)	Bootloader flash (15 kB)
0x0000_4000 to 0x0000_400F	User entry jump vector	User entry jump vector
0x0000_4010 to 0x0007_FFFF	Application flash memory (496 kB	Application flash memory (496 kB
0x0008_0000 to 0x1FFF_FFFF	Reserved	Reserved
0x2000_0000 to 0x2000_03FF	Re-directed interrupt vector table in RAM	Re-directed interrupt vector table in RAM
0x2000_0400 to 0x2000_05FF	Bootloader USB BDTs and buffers	
0x2000_0600 to 0x2000_F7FF	RAM available for bootloader	RAM available for application (63 kB)
0x2000_F800 to 0x2000_FFFF	Stack (2 kB)	Stack (2 kB)

Table 1. MCF52259 bootloader memory map



Functional Description

2.11.2 ColdFire V1 Bootloader Memory Maps

Table 2. MCF51JM128 Bootloader memory map

Addresses	Bootloader	Application
0x(00)00_0000 to 0x(00)00_03FF	Interrupt and exception vectors	Interrupt and exception vectors
0x(00)00_0400 to 0x(00)00_040F	Flash protection and security registers	Flash protection and security registers
0x(00)00_0410 to 0x(00)00_1FFF	Bootloader flash (7kB)	Bootloader flash (7kB)
0x(00)00_2000 to 0x(00)00_21BF	Application interrupt vector table	Application interrupt vector table
0x(00)00_21C0 to 0x(00)00_21C7	User entry jump vector	User entry jump vector
0x(00)00_21C8 to 0x(00)00_21FF	Unused	Unused
0x(00)00_2200 to 0x(00)01_FFFF	Application flash memory (119 kB)	Application flash memory (119 kB)
0x(00)20_0000 to 0x(00)7F_FFF	Reserved	Reserved
0x(00)80_0000 to 0x(00)80_01FF	Re-Directed interrupt vector table in RAM	Re-Directed interrupt vector table in RAM
0x(00)80_0200 to 0x(00)80_06DF	Bootloader USB BDTs and buffers	
0x(00)80_06E0 to 0x(00)80_3BFF	RAM available for bootloader	HAIN available for application (14.5 KB)
0x(00)80_3C00 to 0x(00)80_3FFF	Stack (1 kB)	Stack (1 kB)

2.11.3 MC9S08 Bootloader Memory Maps

Table 3. MC9S08JM60 bootloader memory map

Addresses	Bootloader	Application
0x0000 to 0x00AF	Direct page registers	Direct page registers
0x00B0 to 0x00FF	Zero page RAM	Zero page RAM
0x0100 to 0x105F	RAM available for bootloader	RAM available for application (3.8 kB)
0x1060 to 0x10AF	Stack (80 B)	Stack (80 B)
0x10B0 to 0x17FF	Application flash memory1 (1872 B)	Application flash memory1 (1872 B)
0x1800 to 0x185F	High page registers	High page registers
0x1860 to 0x195F	Bootloader USB BDTs and buffers	Application USB BDTs and buffers
0x1960 to 0xEBA5	Application flash memory2 (52.5 kB)	Application flash memory2 (52.5 kB)
0xEBA6 to 0xEBFC	Application interrupt vector table	Application interrupt vector table
0xEBFD to 0xEBFF	User entry jump vector	User entry jump vector
0xEC00 to 0xFFAD	Bootloader flash (5 kB)	Bootloader flash (5 kB)
0xFFAE to 0xFFBF	Flash protection and security registers	Flash protection and security registers
0xFFC0 to 0xFFFF	Interrupt vectors	Interrupt vectors



2.12 Resource Usage

Table 4 shows the memory resource usage of the bootloader in the three different device examples. As discussed in Section 2.8, "Flash Protection," on page 6, the bootloader is protected in flash. The minimum flash protection size was selected to protect the bootloader. Therefore, the amount of flash used by the bootloader is dictated by the minimum protection size available in the device.

Device	Flash Usage (kBytes)	Secured Flash (kBytes)	RAM Usage ¹ (Bytes)
MCF52259	9	16	0
MCF51JM128	7	8	0
MC9S08JM60	5	5	0

Table 4.	Bootloader	resource	usage
----------	------------	----------	-------

¹ See Section 2.10, "Stack and RAM Usage," on page 7 for explanation why the bootloader uses no RAM

3 CodeWarrior Project Structure

The following sections describe the provided firmware source code for the bootloader and application examples. The source code included with this application note includes the bootloader and examples for all three cores.



CodeWarrior Project Structure

3.1 Bootloader File Structure

Figure 2 shows the directory structure of the provided source code:



MC9S08—Three projects are included. The project "USB Bootloader S08 Standalone" is the bootloader itself. The two application projects are examples that use the bootloader and blink two different LEDs on the DEMOJM board. When building both these applications the bootloader S19 file is included using the HEXFILE command in the Project.prm file. The S19 files from these two applications can be used to demonstrate that the bootloader changes the application firmware.

S19 Files—Is a collection of the S19 files from all the application examples. It also includes the S19 files generated by the CMX example instructions in Section 4, "Using the Bootloader," on page 16. The collection of all the S19 files in this directory makes it convenient to test the bootloader demo by copying the files to the bootloader.

Shared Source—Is a collection of source files shared between multiple projects. The sub-directory **Common_Across_Cores** has the higher level source code for the bootloader that does not change among the three cores. The lower level source files that are specific to the core are in the other sub-directories.

ColdFire V1—Two projects are included. The ColdFire V1 does not have a stand-alone bootloader project. The bootloader source files are directly included with the application project. The two application projects are examples that use the bootloader and blink two different LEDs on the DEMOJM board. The S19 files from these two applications can be used to demonstrate that the bootloader changes the application firmware.

ColdFire V2—Three projects are included. The project **USB Bootloader V2 Standalone** is the bootloader itself, and generates a library file. The two application projects are examples that use the bootloader and blink two different LEDs on the M52259DEMO board. When building the project both of these applications include the bootloader library file. The S19 files from these two applications can be used to demonstrate that the bootloader changes the application firmware.





3.2 ColdFire V2 Project and Files

The ColdFire V2 bootloader has separate projects for the bootloader and application. The bootloader project is in the **USB Bootloader V2 Standalone** directory. It compiles the bootloader source files into a library file called V2_Bootloader.lib. This library file is included in the application project to integrate the bootloader with the application. Figure 3 shows the project window in CodeWarrior for this project. Each file is described below.

USB Bootloader ¥2 Standalone.mcp			
😥 52259 example flash 💽	e 😽 🗧	🦉 💺	▶
Files Link Order Targets			
💉 File	Code	Data 🕴	🥹 🕊 🚊
🖃 🔄 Bootloader Source	8644	2517	• • •
Bootloader_V2.c	4016	2271	•••
Bootloader_V2.h	0	0	• 🔳
📲 Bootloader_Headers.h	0	0	• 🔳
FAT16.c	844	157	•••
📲 Fat16.h	0	0	• 🔳
ParseS19.c	1480	13	•••
ParseS19.h	0	0	• 🔳
SCSI_Process.c	2304	76	• • 🔳
SCSI_Process.h	0	0	• 🔳
🔤 derivative.h	0	0	• 🔳
📄 🖂 opu	1092	0	•••
📄 🕀 🧰 headers	0	0	• 🔳
mcf5xxx_bl.c	8	0	• • 🗉
mcf5225x_vectors.s	1048	0	• • 🗉
mcf5xxx.h	0	0	• 🔳
🔤 mcf5xxx_bl.s	36	0	•••

Figure 3. V2 Standalone bootloader project files

- Bootloader_V2.c—Part-specific file, contains USB stack, manages enumeration, copies USB packets to buffers, and manages flash programming algorithms. Also contains the main bootloader function after bootloader mode is entered.
- Bootloader_V2.h—Part-specific file contains macros for parts of the memory map, macros for the USB and bootloader routines, and structures for the USB peripheral
- Bootloader_Headers.h—Part-specific file points the shared source files to the part-specific header files.
- Fat16.c—Shared file that responds to the host to look like a file allocation table for the drive.
- Fat16.h—Shared header file for Fat16.c
- ParseS19.c—Shared file that parses the S-record file. It verifies each S-record in the file, and after verified, copies the S-record to the specified location in the flash.
- ParseS19.h—Shared header file for ParseS19.c.
- SCSI_Process.c—Shared file that manages SCSI commands from host.
- SCSI_Process.h—Shared header file for SCSI_Process.c.

NP

CodeWarrior Project Structure

- Derivative.h—Part-specific header used to make the shared source compatible with ColdFire V2 bootloader.
- mcf5xxx_bl.c—Part-specific file for exception handler
- mcf5225x_vectors.s—Part-specific file with reset and interrupt vectors. Has the flash protection and security register settings.
- mcf5xxx.h—Part-specific header file for the bootloader
- mcf5xxx_bl.s—Part-specific file for the exception handler.

There are two application examples included that blink different LEDs on the M52259DEMO board. Figure 4 shows the project window of the CodeWarrior project in the directory **USB Bootloader V2 Blinks LED1**. Below is a description of the files included with this project.

USB Bootloader V2 Blinks LED1.mcp					
😝 52259 example flash 💽 🖠	e 😽 🗸	🧭 💺	▶ 📋		
Files Link Order Targets					
💉 File	Code	Data 🕴	🥘 🕊 🔳		
⊡. Sootloader Source	10992	2517	• • 🔳 📥		
Bootloader_V2.h	0	0	• 🔳		
usr_entry_V2.c	208	0	• • 🔳		
- 🎦 V2_Bootloader.lib	9736	2517	• 🔳		
mcf5225x_vectors.s	1048	0	• • 🔳		
🖃 🚍 Application Source	876	16	• • 🔳		
main.c	264	8	•••		
mcf5xxx_lo.s	20	0	• • <u>–</u>		
met5225x_lo.s	172	8	• • <u>–</u>		
mcf5225x_sysinit.c	384	U	• • <u>•</u>		
	36	U	••=		
	U		* =		
mcr52259_bl_stan.lcf	n/a	n/a			
mcroz259_bl_flash.icf	n/a	n/a	· =		
	0	0	· ·		
	U	U	• •		

Figure 4. ColdFire V2 application with bootloader files

- Bootloader_V2.h—Part-specific file contains macros for the device's memory map, macros for the USB and bootloader routines, and structures for the USB peripheral
- usr_entry_v2.c—Part-specific file has the reset entry point and determines whether to enter application or bootloader mode. Required for the bootloader.
- V2_Bootloader.lib—Bootloader library file. Output file from the "USB Bootloader V2 Standalone" project.
- mcf5225x_vectors.s—Part-specific file with reset and interrupt vectors. It has the flash protection and security register settings. Required for the bootloader.
- main.c—Part-specific main file for application. Contains user entry jump vector. Interrupt vectors are initialized in RAM in main().
- mcf5xxx_lo.s—Project-specific, start-up files for application
- mcf5225x_lo.s—Project-specific, start-up files for application



- mcf5225x_sysinit.c—Project-specific, start-up files for application
- mcf5xxx.c—Project-specific, start-up files for application
- mcf52259_bl_sram.lcf—Part-specific linker command file used to load the bootloader and application into SRAM. Enables quick debugging of the application without requiring flash programming.
- mcf52259_bl_flash.lcf—Part-specific linker command file used to store bootloader routines in the protected flash, and application code in the unprotected flash.

3.3 ColdFire V1 Project and Files

The ColdFire V1 bootloader has combined projects for the bootloader and application. There are two application examples included that blink different LEDs on the DEMOJM board. Figure 5 shows the project window of the CodeWarrior project in the directory **USB Bootloader V1 Blinks PTE2**. Below is a description of the files included with this project.



Figure 5. ColdFire V1 application with bootloader project files

- Bootloader_V1.c—Part-specific file, contains USB stack, manages enumeration, copies USB packets to buffers, and manages flash programming algorithms. Contains the main bootloader function after bootloader mode is entered.
- Bootloader_V1.h—Part-specific file contains macros for the device's memory map, macros for the USB and bootloader routines, and structures for the USB peripheral.

CodeWarrior Project Structure

- usr_entry_v1.c—Part-specific file has the reset entry point, determines whether to enter application or bootloader mode.
- Fat16.c—Shared file that responds to the host to look like a file allocation table for the drive.
- Fat16.h—Shared header file for Fat16.c
- ParseS19.c—Shared file that parses the S-record file. It verifies each S-record in the file, and after verified, copies the S-record to the specified location in the flash.
- ParseS19.h—Shared header file for ParseS19.c.
- SCSI_Process.c—Shared file that manages SCSI commands from the host.
- SCSI_Process.h—Shared header file for SCSI_Process.c.
- Bootloader_Headers.h—Part-specific file points the shared source files to the part-specific header files.
- main.c—Project-specific main file for application. Contains user entry jump vector, copies application interrupt vector table to the re-directed interrupt vector table in RAM.
- Project.lcf—Part-specific linker command file used to store bootloader routines in the protected flash and the application code in unprotected flash.

3.4 MC9S08 Project and Files

The MC9S08 bootloader has separate projects for the bootloader and application. The bootloader project is in the **USB Bootloader S08 Standalone** directory. It compiles the bootloader source files into an S19 file called S08_Bootloader.abs.s19. This S19 file is linked into the application project. Figure 6 shows the project window in CodeWarrior for this project. Each file is described below.



			<u> </u>
USB Bootloader S08 Standalone.mcp			
P&E Multilink/Cyclone Pro 🛛 🚽	i	🖌 🔗	ş 🖕
Files Link Order Targets			
✓ File	Code	Data	*
🖃 🔄 Bootloader	4317	1325	• 🔳
📲 Bootloader_S08.c	1442	1268	• 🔳
📲 Bootloader_S08.h	0	0	
Bedirect_Vectors_S08.c	58	0	• 🔳
usr_entry_S08.c	114	0	• 🔳
FAT16.c	936	0	• 🗉
HAI16.h	U 700	U	
Parseb 19.0	762	9	• 픰
	1005	40	. 3
	1005	40	1
Bootloader Headers h	ň	ň	1
The Includes	ŏ	ŏ	
	12672	2190	• 🖬
MC9S08JM60.C	0	172	• 🔳
🋄 ansiis.lib	12672	2018	
🖃 🥽 Project Settings	0	0	
🖻 🥽 Linker Files	0	0	
📲 burner.bbl	n/a	n/a	
Project.prm	n/a	n/a	
🏧 📓 S08_Bootloader.map	n/a	n/a	

Figure 6. S08 Stand-alone bootloader project files

- Bootloader_S08.c—Part-specific file contains USB stack, manages enumeration, copies USB packets to buffers, and manages flash programming algorithms. Contains the main bootloader function after bootloader mode is entered.
- Bootloader_S08.h—Part-specific file contains macros for the device's memory map, macros for the USB and bootloader routines, and structures for the USB peripheral
- Redirect_Vectors_S08.c—Part-specific file contains interrupt vector table in the bootloader for part and points vectors to re-directed interrupt vector table in the application.
- usr_entry_S08.c—Part-specific file has the reset entry point and determines whether to enter application or bootloader mode
- Fat16.c—Shared file that responds to the host to look like a file allocation table for the drive.
- Fat16.h—Shared header file for Fat16.c
- ParseS19.c—Shared file that parses the S-record file. It verifies each S-record in the file, and after verified, copies the S-record to the specified location in the flash.
- ParseS19.h—Shared header file for ParseS19.c.
- SCSI Process.c—Shared file that manages SCSI commands from the host.
- SCSI_Process.h—Shared header file for SCSI_Process.c.
- Bootloader_Headers.h—Part-specific file points the shared source files to the part-specific header files.



- ansiis.lib—Compiler library required for the S08 bootloader.
- Project.prm—Part-specific linker command file used to store bootloader routines in protected flash, and the application code in unprotected flash.

There are two application examples included that blink different LEDs on the DEMOJM board. Figure 7 shows the project window of the CodeWarrior project in the directory **Application with Bootloader S08 Blinks PTE2**. Below is a description of the files included with this project.

Application with Bootloader S08 Blinks PTE2.mcp				
P&E Multilink/Cyclone Pro 🗾	🛱 🔝	* 🚿	\$	
Files Link Order Targets				
🛛 🖉 File	Code	Data	🐇 🚊	
🖃 🔄 Application	12934	2024	• 🔳 📥	
	132	6	• 🔳 🗌	
- 🚺 main.c	130	0	• 🔳	
🄤 🚺 ansiis.lib	12672	2018	I	
🕀 🧰 Includes	0	0	I	
🕀 🧰 Libs	0	172	• 🔳 🔰	
🖃 🥽 Project Settings	0	0		
🖻 🥽 Linker Files	0	0		
📲 burner.bbl	n/a	n/a		
📲 Project.prm	n/a	n/a		
🔤 🔊 S08 Blinks PTF2 man	n/a	n/a		

Figure 7. MC9S08 Application with bootloader project files

- main.c—Project-specific main file for the application. Contains user entry jump vector, and the re-directed interrupt vector table
- Project.prm—Part-specific linker command file used to store bootloader routines in protected flash, and application code in unprotected flash. Links bootloader's S19 file into the application project using HEXFILE command.

4 Using the Bootloader

The following sections describe how to use the bootloader. They include how to demonstrate the bootloader on a development board, and how to integrate with other applications.

4.1 Prevent Cross-Calling

It is important to understand that good bootloaders must only interact with the application through absolute addresses. In this case, the user entry vector resides at an absolute address, and the vector points to the entry point of the application. The bootloader knows this absolute address, when it determines to enter the application mode it jumps to the user entry vector which then jumps to the beginning of the application. This is important because every time the application is re-compiled, the linker might change the address of the entry point. The bootloader does not need to know the changed address because the user entry vector is always at the same location and always points to the application entry point. It is up to the user to ensure



that the user entry vector properly points to the application. This process is described later in this document.

Cross-calling is when the bootloader or application calls a function in another section without an absolute address. This must always be avoided. This bootloader has projects that combine the bootloader and application in a single project. Using a single project has the advantage of programming the device only once in production for both the bootloader and application. It also makes debugging easier. However, having a single project also has the potential for cross-calling and can be hazardous.

Consider this scenario:

A bootloader is used with an ANSI library and compiled in the same project with an application that uses the same library. RevA of the firmware is compiled and a library function called MyFunc() is linked into the bootloader section at address 0x100. The application also uses MyFunc() and cross-calls into the bootloader while executing it. RevA is released for production and everything works fine. After some time passes, the firmware is updated to RevB. While re-compiling the project, the linker moves MyFunc() to address 0x105. The bootloader and application for RevB are linked together, so this version works fine as is. Now the firmware update for RevB is uploaded into a device with the RevA bootloader. The application is updated to RevB, but the bootloader is still RevA. When the application executes and cross-calls MyFunc(), it jumps to address 0x105, but MyFunc() in the RevA bootloader is at address 0x100, and the code will runaway.

This example demonstrates why cross-calling between the application and the bootloader must always be avoided except through absolute addresses.

The only interaction this bootloader has with the application is when the bootloader launches the application that uses the absolute address of the user entry vector. The MC9S08 version of this bootloader integrates with the application differently than the ColdFire versions. The ColdFire versions include the bootloader source or library with the application project. The MC9S08 version of the bootloader uses the ANSI library ansiis.lib. To prevent a cross-call scenario, the MC9S08 bootloader is compiled as a separate project. The S19 file from the bootloader project is included with the application project using the HEXFILE command in the PRM linker file. With this method, the linker is not aware of the library functions in the bootloader while compiling the application and there is no cross-calling. The application project continues to include the bootloader code and continues with the benefit of programming only once in production.

When compiling the bootloader with the application, cross-calling must be tested before a production release of the firmware. An easy method to test that the bootloader does not cross-call application functions is to erase the application and test that the bootloader continues to work properly. This bootloader is self-sufficient and works when no application is present. To use this test method, program the device with the combined bootloader and application project. Then, erase the application sectors of flash. These sectors can be erased manually or the debugger can be used. With the debugger, place a breakpoint immediately after the bootloader erases the application during an update. Exercise the bootloader to update the firmware and when the breakpoint is reached, force a reset. The bootloader should continue to function normally. If it does not, the bootloader has a cross-call into the application. Use the debugger to find where the cross-call occurs, and then modify the project to remove the cross-call.

Test that the application does not cross-call into the bootloader. One method to do this is to carefully read the .MAP file after compiling. Read all the functions stored in the bootloader portion of the flash and make



sure they are functions used only by the bootloader, not the application. Ensure no libraries are included in the bootloader. Check any start-up routines used, because those function names might be used by both the bootloader and the application. Another method to test for cross-calling is to erase the bootloader and test the application. This method can be tricky because the reset and interrupt vectors are also located in the bootloader section.

4.2 Using Bootloader on the Demo Board

The included CodeWarrior projects have application examples to test with the M52259DEMO and the DEMOJM development boards. Choose a core to test with the corresponding board. Please refer to the documentation included with these boards to get started and learn how to program the boards with CodeWarrior. After getting familiar with the boards and CodeWarrior, follow these steps:

- 1. The hardware must be setup for USB device operation. Use the default jumper settings. Refer to the board documentation for more details. If using the DEMOJM board, ensure that the proper MC9S08 or ColdFire V1 module is plugged into the board. Plug both USB cables into the board and the computer.
- 2. Open the corresponding CodeWarrior and open one of the .MCP project files for one of the application examples. With a ColdFire V2 project, make sure the target "52259 Example Flash" is selected. Compile the project and program the flash.
- 3. Reset the board. One of the LEDs flashes on the board. This shows the application is running.
- 4. Force the bootloader mode by holding down a button on the board, then press and release the Reset button. For the DEMOJM board, use button PTG0. For the M52259DEMO board, use button SW1. The device reboots in bootloader mode and enumerates a new drive in the host computer. Figure 8 shows the bootloader drive in Windows XP. Notice the volume name of the drive is BOOTLOADER, and the status file is READY.TXT. The bootloader is now ready to receive an S19 file.





- 5. Go to the directory "S19 Files", copy one of the S19 files for that core and paste it into the bootloader drive. Dragging and dropping the file also works. In the directory **S19 Files**, choose either an S19 file that blinks another LED or choose the CMX Example S19 file that loads the HID
- 6. Some operating systems like Linux Fedora 8 do not transfer the file to the drive until the drive is unmounted. If using an operating system like this, unmount the bootloader drive.
- 7. Check the bootloader file status. After the file transfer is complete, the bootloader drive disappears. After a few seconds, the drive re-enumerates and re-appears. Click on the bootloader drive to verify the status file is SUCCESS.TXT. The firmware update is then complete.

example.





Figure 9. Bootloader drive with successful status file

8. Reset the board using the **Reset** button. The new application is then executed. If the CMX example S19 file was used, the mouse pointer wiggles back and forth on the host computer. If one of the other S19 files were used, a LED blinks on the board. To repeat the process and load another S19 file, go back to step 4.

4.3 Creating a New Project with the Bootloader

The bootloader is intended to be integrated with other applications. The provided application examples are templates that can be used to get started. Starting a new project with the bootloader is simple because the application examples can be used as a starting point. Integrating the bootloader with existing applications is more difficult and requires several modifications. These steps are listed in the following sections.

When starting a new project with the bootloader, begin the process by modifying one of the application examples with the new application. The application example already has the bootloader integrated and has the start-up functions provided. You can start writing the new application functionality in the main() in main.c. The only change that needs to be made to the application example is the interrupt vector table. The re-directed interrupt vector table is different for each core and is discussed in greater detail in the following sections.

4.3.1 Modifying the ColdFire V2 Interrupt Vector Table

The ColdFire V2 core has a feature to change the base address of the interrupt vector table. The register VBR stores the base address of the vector table and can be changed as you go along. Out of reset, the VBR is 0x0, which places the vector table in the protected flash sector. Therefore, the reset vector is at address 0x4 and is also protected and controlled by the bootloader. After the application starts, the application can



change the VBR to place the vector table in the RAM. Then the application can load its interrupt vectors into the RAM vector table.

```
void main (void)
{
    // Set the interrupt handlers in the vector table
    mcf5xxx_wr_vbr((uint32)__VECTOR_RAM);
    mcf5xxx_set_handler(64 + 55, (long)pit0_isr);
    Figure 10. ColdFire V2 re-directing interrupt vectors
```

Figure 10 shows the two lines of code used in the ColdFire V2 application example to redirect the interrupt vector table to RAM and load the vector table. The first line uses the function mcf5xxx_wr_vbr() to place the vector table in the RAM. The second line uses the function mcf5xxx_set_handler() to load a vector into the vector table. In this example, the interrupt is for the Periodic Interrupt Timer0 and the ISR associated with this interrupt is pit0_isr(). In the MCF52259, the PIT0 interrupt vector is the 55th vector for Interrupt Controller0. Therefore, the vector number is 64 + 55.

When changing the vector table for the new application, use the mcf5xxx_set_handler() to set the new vectors to point to the appropriate ISRs.

4.3.2 Modifying ColdFire V1 Interrupt Vector Table for a New Application

The ColdFire V1 core has a feature to change the base address of the interrupt vector table. The register VBR stores the base address of the vector table and can be changed as you go along. Out of reset, the VBR is 0x0, this places the vector table in the protected flash sector. Therefore, the reset vector is at address 0x4 and is also protected and controlled by the bootloader. After the application starts, the application can change VBR to place the vector table in the RAM. Then the application can load its interrupt vectors into the RAM vector table.

The ColdFire V1 application stores its own vector table in the flash. Figure 11 shows a portion of the vector table called RAM_vector stored in the application flash. The whole table can be seen in Appendix F, "hid_main.c for the ColdFire V1 CMX Example," on page 61. Because this vector table is stored in the application flash, the bootloader can update with a new firmware update.



```
void (* const RAM_vector[])()@REDIRECT_VECTORS= {
                                       // vector_0
    (pFun)&dummy_ISR,
                                                      INITSP
    (pFun)&dummy_ISR,
(pFun)&dummy_ISR,
                                      // vector_1
                                                     INITPC
                                      // vector_2
                                                    Vaccerr
                                      // vector_75 Vtpm1ch4
// vector_76 Vtpm1ch5
    (pFun)&dummy ISR,
     (pFun)&dummy_ISR,
    (pFun)&Timer_Overflow,
                                           // vector_77 Vtpmlovf
    (pFun)&dummy_ISR,
                                      // vector_78 Vtpm2ch0
    (pFun)&dummy_ISR,
                                      // vector_79 Vtpm2ch1
};
```



```
void main(void) {
    /* !! This section needs to be here to redirect interrupt vectors !! */
    dword *pdst.*psrc;
    byte i;
    asm (move.l #0x00800000,d0);
    asm (movec d0,vbr);
    pdst=(dword*)0x00800000;
    psrc=(dword*)&RAM_vector;
    for (i=0;i<111;i++,pdst++,psrc++)
    {
        *pdst=*psrc;
    }
    /* !! Start application code below here !! */
</pre>
```

Figure 12. ColdFire V1 interrupt re-direction

When the application starts, the first two lines load the VBR with the RAM vector table location that re-directs the interrupt vector table to the RAM. Then the loop copies the application vector table from the flash to the RAM.

With a new application, load the RAM_vector array with the ISR functions at the appropriate vector location.

4.3.3 Modifying the MC9S08 Interrupt Vector Table for the New Application

The MC9S08 core cannot re-direct the vector table to the RAM like ColdFire. Instead, the bootloader points to the interrupt vectors to a re-directed table in the application flash. The re-directed vector table is stored at a specific address. In Figure 13, the array UserJumpVectors in main.c is the re-directed vector



```
Using the Bootloader
```

table, and it starts at address VectorAddressTableAddress, which is 0xEBA6. Notice in the table, each ISR address is preceded by the value 0xCC. This value is the JMP op-code.

// User Interrupt Jump Vector Table	tore[InterruptVectoreNum]@ VectorAddreesTableAddrees = J
Oracine Const Sumprect OserSumprec	tors[interrupt/ectorsnum]@ /ectorsnumessiablesudress -]
{ OXCC, Dummy_ISR},	22 - RIC
{ UXCC, Dummy_ISR},	
{ UxCC, Dummy_ISR},	ZZ ZZ - ACMP
{ UxCC, Dummy_ISR},	// 26 - ADC Conversion
{ OxCC, Dummy_ISR},	// 25 - KBI
{ OxCC, Dummy_ISR},	// 24 - SCI2 Transmit
{ 0xCC, Dummy_ISR},	// 23 - SCI2 Receive
{ OxCC, Dummy_ISR},	// 22 - SCI2 Error
{ 0xCC, Dummy_ISR},	// 21 - SCI1 Transmit
{ 0xCC, Dummy_ISR},	// 20 - SCI1 Receive
{ OxCC, Dummy ISR},	// 19 - SCI1 Error
{ OxCC, Dummy ISR},	// 18 - TPM2 Overflow
{ OxCC, Dummy ISR},	// 17 - TPM2 Channel1
{ OxCC, Dummy ISR},	// 16 - TPM2 Channel0
{ OxCC, Timer Overflow},	// 15 - TPM1 Overflow
{ OxCC, Dummy ISR}.	// 14 - TPM1 Channel5
{ 0xCC, Dummy ISR}.	// 13 - TPM1 Channel4
{ OxCC, Dummy ISR}	// 12 - TPM1 Channel3
{ DxCC Dummy ISR}	// 11 - TPM1 Channel2
{ OxCC Dummy ISR}	// 10 - TPM1 Channel1
{ OwCC Dummy ISR}	9 - TPM1 Channel0
{ OxCC Dummy ISR}	// 8 - Reserved
{ Owcc Dummy ISR}	77- IISB Status
(DwCC, Dummy ISR)	
(OrrCC Dummer ISP)	
(DreCC, Dummer ISB)	// J MCC Loop of Look
{ OxCC, Dummy_ISR}, { OrCC, Dummy_ISR}	// 4 - NCG LOSS OF LOCK
{ DXCC, Dummy_ISK}, { DxCC, Dummy_ISK},	// 3 - LOW VOILAYE DELECT
{ OxCC, Dummy_ISR},	$\gamma \gamma \gamma \gamma = 1 \pi Q$
{ UXCC, DUMMY_ISK},	// I - 5WI
31	

Figure 13. MC9S08 Application re-directed interrupt vector table

The bootloader uses the array BootIntVectors in the file Redirect_Vectors_S08.c to load the interrupt vector table in the bootloader flash (see Figure 14 on page 24). These vectors point to the re-directed application vectors in Figure 13. When an interrupt occurs, the interrupt controller reads the vector from the BootIntVectors table in the bootloader flash. It changes the program counter (PC) to the loaded address, that is the re-directed vector in the UserJumpVectors table in the application flash. The core executes the 0xCC JMP op-code, followed by the ISR's address, and then PC jumps to the ISR.



<pre>// Bootloader Redirected Interrupt Vectors const unsigned int BootIntVectors[InterruptVectorsNum]@BootVectorTableAddress = { VectorAddressTableAddress+3, VectorAddressTableAddress+4, VectorAddressTableAddress+9, VectorAddressTableAddress+12, VectorAddressTableAddress+12, VectorAddressTableAddress+12, VectorAddressTableAddress+21, VectorAddressTableAddress+24, VectorAddressTableAddress+24, VectorAddressTableAddress+30, VectorAddressTableAddress+30, VectorAddressTableAddress+31, VectorAddressTableAddress+31, VectorAddressTableAddress+31, VectorAddressTableAddress+31, VectorAddressTableAddress+30, VectorAddressTableAddress+30, VectorAddressTableAddress+33, VectorAddressTableAddress+33, VectorAddressTableAddress+34, VectorAddressTableAddress+34, VectorAddressTableAddress+34, VectorAddressTableAddress+45, VectorAddressTableAddress+45, VectorAddressTableAddress+51, VectorAddressTableAddress+51, VectorAddressTableAddress+51, VectorAddressTableAddress+51, VectorAddressTableAddress+51, VectorAddressTableAddress+52, VectorAddressTableAddress+54, VectorAddressTableAddress+54, VectorAddressTableAddress+54, VectorAddressTableAddress+54, VectorAddressTableAddress+55, VectorAddressTableAddress+56, VectorAddressTableAddress+57, VectorAddressTableAddress+50, VectorAddressTableAddress+50, VectorAddressTableAddress+66, VectorAddressTableAddress+65, VectorAddressTableAddress+65, VectorAddressTableAddress+66, VectorAddressTableAddress+65, VectorAddressTableAddress+66, VectorAddressTableAddress+66, VectorAddressTableAddress+57, VectorAddressTableAddress+57, VectorAddressTableAddress+66, VectorAddressTableAddress+65, VectorAddressTableAddress+65, VectorAddressTableAddress+65, VectorAddressTableAddress+65, VectorAddressTableAddress+65, VectorAddressTableAddress+65, VectorAddressTableAddress+57, VectorAddre</pre>	
VectorAddressTableAddress+69, VectorAddressTableAddress+72, VectorAddressTableAddress+75, VectorAddressTableAddress+78,	
VectorAddressTableAddress+81, VectorAddressTableAddress+84, };	

Figure 14. MC9S08 bootloader interrupt vector table

For a new application, load the array UserJumpVectors in main.c with the proper application ISRs.

4.4 Adding the Bootloader to the Existing ColdFireV2 Project

This section gives step-by-step instructions on how to take an existing ColdFire V2 CodeWarrior project and add the bootloader. This example uses the HID-DEMO from CMX for the ColdFire V2 with the complimentary CMX USB stack. For licensing reasons, the CMX source code is not included with this application note's firmware. However, the following steps give instructions on how to take the CMX example and add the bootloader. The CMX software is included in the DVD that comes with the MCF52259 board. The document titled *MCF52259 CMX USB LITE Lab Tutorial* data sheet (document M52259CMXUSBLAB) describes how to use the CMX example with the board.

The following steps reference directories and files for both the bootloader and CMX example. The bootloader files and paths are referenced from the root directory of this application note's firmware. The CMX example files and paths are referenced from the root directory of the CMX software installation.

1. Remove any references to the reset and interrupt vectors in the application. The bootloader uses the reset vector to point to its start-up function that determines if the bootloader or application mode must start. If the application keeps a reset vector reference, this can cause an error because two vectors attempt to use the same location.

A common method for the reset vector is to provide a constant vector table in a project file, for example the mcf5222x_vectors.s. This vector table is forced to the proper flash location for the vectors either by using a fixed address in the vector table declaration, or by using a segment



declared in the LCF file. For the bootloader, this vector table must be removed. The interrupts are re-directed in the steps below.

For this CMX example, it uses the same vector table as the bootloader in mcf5222x_vectors.s. To integrate the bootloader with the CMX example, the bootloader version of the vector table is used. The CMX example version needs to be changed to keep the start-up function. Modify the following file with the steps below:

\usb-peripheral\projects\CodeWarrior\mcf52223\mcf5222x_vectors.s

- a) Remove the VECTOR_TABLE with all the interrupt vectors. This table is replaced by the bootloader's vector table.
- b) Remove the following non-volatile register settings. These register settings are replaced by the bootloader.

.org Ox	400	
KEY_UPPER:	.long	0x00000000
KEY_LOWER:	.long	0x00000000
CFMPROT:	.long	0x00000000
CFMSACC:	.long	0x00000000
CFMDACC:	.long	0x00000000
CFMSEC:	.long	0x00000000

c) Modify the start function. This modified example needs to reference the start function in assembly from C. Change the declaration of the function by adding an underscore before the label so that C functions can reference it:

_start:

d) Add another global declaration for the start function so that C files can reference it. Add this line with the other global declarations:

```
.global start
```

- e) Because many modifications were made to mcf5222x_vectors.s, the entire source code for this file is given in Appendix A, "mcf5222x_vectors.s for the Coldfire V2 CMX Example," on page 43.
- 2. Copy the following files from the bootloader project into the application project using the directories below. After copying, add these files to the CodeWarrior project. To do this, in CodeWarrior right-click in the project window, and select **Add Files** navigate to the files below, select them all and click **Open**. Then select **OK**.

Bootloader_V2.h mcf5225x_vectors.s usr_entry_V2.c V2_Bootloader.lib

Directory

From: \Shared Source\V2_Source

To: \usb-peripheral\src\mcf5222x\hid-demo

3. The bootloader files should now be visible in the CodeWarrior Project window shown in Figure 15.



			×						
hid_demo.mcp									
🐞 hid-demo-flash-demokit 🔽 🚦	B 😽 🤻	ş 💺 ı							
Files Link Order Targets									
🛛 File	Code	Data 🔞	🖌 😸 🔺						
⊞ 🛅 usb-drv	7724	579 •	• •						
🚺 target.c	392	0 •	• • •						
🚺 hid.c	2592	34 •	• • 🔳 📗						
🚺 hid_kbd.c	608	7 •	• • 🖬						
🚺 hid_mouse.c	172	4 •	• • 🖬						
📓 hid_generic.c	364	1•	• • 🗉 📔						
📓 hid_usb_config.c	1264	919 •							
📓 startup.c	152	0 •							
mcf5222x_vectors.s	100	8 •	• •						
s.ol_xxxdtom	388	0 •	• •						
m522x_evb_flash.lcf	n/a	n/a •							
	1512	U •							
Maine Maine Marker (h. 1977)	252	0517 ·	· · 프						
	9736	2017 •	김 김						
	1040	0							
mcrozzox_vectors.s	1048	0							
usr_entry_vz.c	192	0 •	• =						

Figure 15. ColdFire V2 CMX example project window files

- 4. Copy/Edit the LCF linker file. The LCF file is critical when integrating the bootloader with an application. The bootloader LCF file must be used as the template for the new application LCF file. However, modifications may be required based on the application. The existing application's LCF file needs to be well understood. For more information on linker files, please read the *CodeWarrior Build Tools Reference Manual*. Pay particular attention to the memory sections, and stack settings of the existing LCF file. For this CMX example, the following modifications are required.
 - a) Use the provided bootloader LCF file as the starting template. Copy and rename the file below overwriting the original LCF file with the CMX example.

Directory

 From:
 \Shared Source\V2_Source\mcf52259_bl_flash.lcf

 To:
 \usb-peripheral\projects\CodeWarrior\mcf52223\m522x_evb_flash.lcf

b) Add the USB buffer descriptor table (BDT) settings to the LCF file. This CMX example uses the LCF to determine where to place the USB buffer descriptor table. From the original LCF file with this CMX example, copy the code below and paste into the modified LCF after the following line in the .bss section: BSS END = .;



```
\_BDT\_END = .;
```

- c) Because these modifications were made to this LCF file, the entire source code for the LCF file is given in Appendix B, "LCF File for ColdFire V2 CMX Example," on page 47.
- 5. Modify the main application file to integrate with the bootloader. For this CMX example, modify hid main.c with the following:
 - a) Include the Bootloader_V2.h header file in the main application file. Add the following line to hid_main.c:

```
#include "Bootloader V2.h"
```

b) Add the user entry jump vector to the main application file. For this CMX example, the user entry point is start. Add the following code to hid_main.c:

```
extern asm void start(void);
void usb_it_handler(void);
const byte _UserEntry[] @ USER_ENTRY_ADDRESS = {
    0x4E,
    0x71,
    0x4E,
    0xF9 //asm NOP(0x4E71), asm JMP(0x4EF9)
};
void (* const _UserEntry2[])()@(USER_ENTRY_ADDRESS+4) = {
    start,
};
```

c) Add the re-directed interrupt vectors to the RAM. In this CMX example, only the USB interrupt is used. The USB interrupt is vector 53 and needs to point to the ISR usb_it_handler(). Add the following code to the start of the main function before hw_init() is called:

```
VECTOR RAM[64 + 53] = (hcc u32) usb it handler;
```

- d) Re-direct the interrupt vectors to RAM. Add the line below after hw_init() is called. It is important to add this line after hw_init() because hw_init() sets VBR to point to the flash: mcf5xxx_wr_vbr((hcc_u32) __VECTOR_RAM);
- e) Because several changes were made to the hid_main.c file, Appendix C, "hid_main.c for ColdFire V2 CMX Example," on page 51 provides the source code for the entire file.

NP

Using the Bootloader

6. Compiling at this point can cause errors because the CMX example uses different header files used for the ColdFire registers than for the bootloader. Modify Bootloader_V2.h and usr_entry_V2.c by changing the code below to include the other header file:

```
#include "support_common.h"
to
    #include "mcf5222x_reg.h"
```

- 7. Compiling at this point can cause errors because usr_entry_V2.c references the start-up function for the bootloader example. There are two references in this file to asm_startmeup. Replace both with start. Refer to Appendix D, "usr_entry_V2.c for ColdFire V2 CMX Example," on page 54 for the full source file.
- 8. Change the entry point for the linker. The linker needs to know what function is the entry point. This needs to be modified to point to the bootloader __Entry function. Change the project properties by clicking on the Edit Menu -> hid_demo-flash-demokit Settings, select ColdFire Linker in the Target Settings Panel on the left. Change the entry point to __Entry.

NOTE

Entry has 2 underscores.

Then click OK.

🖻 hid-demo-flash-demokit Settings [hid_demo.mcp]								
S Target Settings Panels	ColdFire Linker							
Target Settings Paries Target Settings Access Paths Build Extras Runtime Settings File Mappings Coldfire Target Coldfire Target Language Settings C/C++ Language C/C++ Preprocessor C/C++ Warnings ColdFire Assembler	 Generate Symbolic Info Store Full Path Names Generate Link Map List Unused Objects Show Transitive Closure Always Keep Map Generate S-Record File Generate Listing File Generate Binary Image Entry Point:Entry 	 Disable Deadstripping Generate ELF Symbol Table Generate Warning Messages Warn Superseded Definitions Max S-Record Length: 80 EOL Character: DOS Max Bin Record Length: 252 						
ColdFire Processor Global Optimizations ⊢ Linker ELF Disassembler ColdFire Linker	Force Active Symbols: Factory Settings Revert	Import Panel Export Panel OK Cancel Apply						

Figure 16. ColdFire V2 CMX example linker settings



9. Compile and download the project into the board. The CMX example works as described in the *MCF52259 CMX USB LITE Lab tutorial* document. Hold down the SW1 button while pressing and releasing the Reset button to enter bootloader mode. The bootloader drive appears in the PC. Copy another application's S19 file onto the drive to see the application change. For example, use either the ColdFire V2 S19 file in the bootloader directory \S19 Files. Enter bootloader mode again and copy the CMX example S19 file back to the board using the file

\usb-peripheral\projects\CodeWarrior\mcf52223\hid-demo\hid-demo.elf.S19.

4.5 Adding Bootloader to the Existing ColdFire V1 Project

This section gives step-by-step instructions on how to take an existing ColdFire V1 CodeWarrior project and add the bootloader. This example uses the HID-DEMO from CMX for the ColdFire V1 with the complimentary CMX USB stack. For licensing reasons, the CMX source code is not included with this application note's firmware. However, the steps below give instructions on how to take the CMX example and add the bootloader. The CMX software can be downloaded from Freescale's website at http://www.freescale.com/usb.

The steps below reference directories and files for both the bootloader and CMX example. The bootloader files and paths are referenced from the root directory of this application note's firmware. The CMX example files and paths are referenced from the root directory of the CMX software installation.

 Copy the following files from the bootloader project into the application project using the directories below. After copying, add these files to the CodeWarrior project. To do this, in CodeWarrior right-click on the hid-demo file group in the project window, and select Add File Navigate to the files below, select them all and click Open. Then select OK.

Bootloader_V1.c Bootloader_V1.h exceptions.c exceptions.h usr_entry_V1.c Bootloader Headers.h

Directory

 From:
 \Shared Source\V1_Source\

 To:
 \usb-peripheral\projects\CodeWarrior-6.x\mcf51xx\hid-demo\Sources\

- 2. Copy the following files from the bootloader project into the application project using the directories below. After copying, add these files to the CodeWarrior project just like the previous step.
 - FAT16.c FAT16.h ParseS19.hc ParseS19.h SCSI_Process.c SCSI_Process.h



Directory

From: \Shared Source\Common_Across_Cores\

To: \usb-peripheral\projects\CodeWarrior-6.x\mcf51xx\hid-demo\Sources\

3. The bootloader files are now visible in the CodeWarrior Project window as shown in Figure 17:

hid_demo.mcp			X
P&E Multilink/Cyclone Pro 📃 🌐	10 😽	🏼 🎺 💺	
Files Link Order Targets			
🛛 File	Code	Data 🔞	4 🛓
 File target.c mcf5xxx_lo.s hid-demo hid.c hid_generic.c hid_generic.h hid_kbd.c hid_kbd.c hid_mouse.c hid_usb_config.c hid_usb_config.h usr_entry_V1.c Bootloader_Headers.h Bootloader_V1.c Bootloader_V1.c Bootloader_V1.h SCSI_Process.h FAT16.c Fat16.h ParseS19.c ParseS19.h SCSI_Process.c 	Code 376 56 9772 1534 0 246 0 450 0 220 134 0 726 0 182 0 3002 0 3002 0 540 0 1174 0 1564 6166	Uata 2906 • 2906 • 2906 • 34 • 0 • 1 • 0 • 452 • 4 • 0 • 919 • 0 • 919 • 0 • 1243 • 0 • 1257 • 0 • 13 • 0 • 13 • 0 •	▲ ■ ■ ■ ■ ■ ■ ■ ■ •
⊞-t Includes ⊕-t Libs ⊕-t Project Settings	0 34678 858	0 • 2459 • 444 •	· 피 • 피

Figure 17. ColdFire V1 CMX Example project window files



4. Copy/Edit the LCF linker file. The LCF file is critical when integrating the bootloader with an application. The bootloader LCF file must be used as the template for the new application LCF file. However, modifications may be required based on the application. The existing application's LCF file needs to be well understood. For more information on linker files, please read the *CodeWarrior Build Tools Reference Manual*. Pay attention to the Memory sections, and Stack settings of the existing LCF file. For this CMX example, several modifications are required. Open the CMX example LCF file below and make the following changes:

\usb-peripheral\projects\CodeWarrior-6.x\mcf51xx\hid-demo\prm\Project_flash.lcf

a) The MEMORY section needs to be modified to segment the memory into the bootloader and application partitions. Overwrite the MEMORY section in the LCF file with the MEMORY section used in the bootloader example LCF file. Overwrite with the text below:

MEI	MORY {								
	bootcode	(RX)		ORIGIN	=	0×000410	LENGTH	=	0x00001BF0
	code	(RX)	:	ORIGIN	=	0×0.02200	LENGTH	_	0x00001E10
	#codo	(DV)	:	ORIGIN	_	0x002200,	IENCTU	_	0x0001000
	#coue #usorrom	(RA) (DWV)	:	ORIGIN	_	0x000410,	LENGIII	_	0x00011BF0
	#userram	(RWA)	:	ORIGIN	_	0.2000000,	LENCTU	_	0x00004000
	vectorram	(RWA)	•	ORIGIN	_	0000000,	LENGIA	_	0x00000200
	userram	(RWA)	•	ORIGIN	_	0x000200,	LENGIA	_	0X00003E00
1	poolsram	(RWX)	:	ORIGIN	=	UX8006E0,	LENGTH	=	0X00003B00
}									

b) The stack size needs to be increased. The bootloader and application share the stack, it must be the same size and location of the bootloader. Change the stack size by changing the line below:

____stack_size = 0x400;

c) The bootloader sections need to be added to the LCF file to tell the linker where to place the bootloader code and RAM. Copy the following sections from the bootloader example LCF file into the CMX example LCF file, and add below the .code section:

```
.bootcode:
    {
        Boot START
                    = .;
        Bootloader_V1.c (.text)
        Bootloader V1.c (.rodata)
        usr entry V1.c (.text)
                      (.text)
        ParseS19.c
        ParseS19.c
                       (.rodata)
        SCSI Process.c (.text)
        SCSI Process.c (.rodata)
        FAT16.c
                      (.text)
        FAT16.c
                       (.rodata)
        exceptions.c (.text)
         = ALIGN (0x4); 
         Boot_END
                       =.;
 } > bootcode
 .bootsram:
    {
        Boot RAM START
                         = .;
        Bootloader_V1.c
                                      (.bss)
        Bootloader V1.c
                                      (.sbss)
```



```
usr_entry_V1.c
                                       (.bss)
      usr entry V1.c
                                       (.sbss)
      ParseS19.c
                                         (.bss)
                                         (.sbss)
      ParseS19.c
      SCSI Process.c (.bss)
      SCSI Process.c
                        (.sbss)
      FAT16.c
                                                                 (.bss)
      FAT16.c
                                                                (.sbss)
      = ALIGN (0x4);
       ___Boot_RAM END
                          =.;
} > bootsram
```

d) The stack location needs to be changed in the .custom section of the LCF file. The bootloader and application share the stack, it must be the same size and location of the bootloader. Use the bootloader example LCF file to see where the stack should be located, and change the .custom section as shown below:

```
.custom :
{
    ____HEAP_START = .;
    ____heap_addr = ___HEAP_START;
    ____HEAP_END = ___HEAP_START + ___heap_size;
    . = ___HEAP_END;
    . = ALIGN(512);
    __BDT_BASE = .;
    . = . + 512;
    ___BDT_END = .;

    ___SP_INIT = ___RAM_ADDRESS + ___RAM_SIZE;
    ___SP_END = ___SP_INIT - ___stack_size;
} >> userram
```

- e) Because several modifications were made to this LCF file, the entire source code for the LCF file is given in Appendix E, "LCF File for ColdFire V1 CMX Example," on page 57.
- 5. Modify the main application file to integrate with the bootloader. For this CMX example, modify hid_main.c with the following:
 - a) Include the Bootloader_V1.h header file in the main application file. Add the following line to hid_main.c:

#include "Bootloader_V1.h"



b) Add the user entry jump vector to the main application file. For this CMX example, the user entry point is startup(). Add the following lines to hid main.c:

c) Remove any references to a reset vector in the application. The bootloader uses the reset vector to point to its start-up function that determines if the bootloader or application mode start. If the application keeps a reset vector reference, this can cause an error because two vectors attempt to use the same location.

A common method for the reset vector is to provide a constant vector table in a project file, for example exceptions.c. This vector table is forced to the proper flash location for the vectors either by using a fixed address in the vector table declaration, or by using a segment declared in the LCF file. For the bootloader, this vector table must be removed. Interrupts are re-directed in the steps below.

For this CMX example, the existing application used a vector table in exceptions.c to reference _startup(). Overwriting the exceptions.c file has already implemented this change.

d) The re-directed interrupt vector table is added in the next step. To prepare for it, copy the following lines to the hid main.c:

```
__interrupt void dummy_ISR(void) {}
typedef void (* pFun)(void);
```

e) Add the re-directed interrupt vector table, and point the re-directed vectors to the application's interrupt service routines. In this CMX example, only the USB interrupt is used. The vector table is too large to display in its entirety here. Copy the entire RAM_vector[] table from the bootloader application example file \V1 USB Bootloader Projects\USB Bootloader V1 Blinks PTE2\Sources\main.c to the hid_main.c file. Then, change the ISR name for USB vector 69 to usb_it_handler. The bootloader application also used a timer interrupt. Change that vector 77 to dummy_ISR. Below gives a snapshot of the modified CMX Example vector table:

```
void (* const RAM_vector[])()@REDIRECT_VECTORS= {
   (pFun)&dummy_ISR, // vector_0 INITSP
   (pFun)&dummy_ISR, // vector_1 INITPC
   .
   .
   (pFun)&dummy_ISR, // vector_68 Vspi2
   (pFun)&usb_it_handler, // vector_69 Vusb
   (pFun)&dummy_ISR, // vector_70 VReserved70
   (pFun)&dummy_ISR, // vector_71 Vtpm1ch0
```



```
(pFun)&dummy ISR,
                        // vector 72 Vtpmlch1
                        // vector 73 Vtpm1ch2
    (pFun)&dummy ISR,
    (pFun)&dummy ISR,
                       // vector 74 Vtpm1ch3
    (pFun)&dummy ISR,
                       // vector 75 Vtpm1ch4
                       // vector_76 Vtpm1ch5
    (pFun)&dummy ISR,
                       // vector 77 Vtpmlovf
    (pFun)&dummy ISR,
    (pFun)&dummy ISR,
                       // vector 78 Vtpm2ch0
    (pFun)&dummy ISR,
                        // vector 110 VL1swi
};
```

f) The application needs to re-direct the interrupts to RAM and needs to copy the interrupt vectors from the flash to RAM. For this CMX example, copy the following to the beginning of main() in hid_main.c:

```
/* !! This section needs to be here to redirect
interrupt vectors !! */
dword *pdst,*psrc;
byte i;
asm (move.l #0x00800000,d0);
asm (movec d0,vbr);
pdst=(dword*)0x00800000;
psrc=(dword*)&RAM_vector;
for (i=0;i<111;i++,pdst++,psrc++)
{
*pdst=*psrc;
}
/* !! Start application code below here !! */
```

- g) Because several changes were made to the hid_main.c file, Appendix F, "hid_main.c for the ColdFire V1 CMX Example," on page 61 provides the source code for the entire file.
- 6. Change the existing interrupt vector table. The existing application places the interrupt vector table in the protected bootloader flash memory. These vectors need to be re-directed. The first step is to change references in the application to the existing interrupt service routines.

If an interrupt vector number is used when the ISR is declared, CodeWarrior loads that interrupt vector with the address of the declared ISR. With the bootloader, these interrupt vector numbers need to be removed from the ISR declaration.

Another common method for vector tables is to provide a constant vector table in a project file, for example exceptions.c. This vector table is forced to the proper flash location for the vectors either by using a fixed address in the vector table declaration, or by using a segment declared in the LCF file. For the bootloader, this vector table must be removed.

NP

For this CMX example, the only interrupt used is the USB interrupt. The interrupt vector number of the usb_it_handler ISR declaration needs to be removed. Change the line below in usb.c to the following:

```
interrupt VectorNumber_Vusb void usb_it_handler(void)
to
interrupt void usb it handler(void)
```

 Change the compiler optimization. The CMX example turns off all optimizations, so the bootloader code does not fit into the protected sectors. To change this, open the Menu Edit -> DEMOJM Flash Settings, then select Global Optimizations. Change the optimization to Level 1.

DEMOJM Flash Settings [hid_demo.mcp]							
Target Settings Panels	Global Optimizations						
 □ Target □ Target Settings □ Access Paths □ Build Extras □ File Mappings □ Source Trees □ Coldfire Target □ OSEK Sysgen □ Language Settings □ C/C++ Language □ C/C++ Varnings □ ColdFire Assembler □ ColdFire Processor 	Optimize For: • Faster Execution Speed • Smaller Code Size Larger Code Smaller Code Harder Debugging Faster Compiles Faster Compiles Slower Compiles I I I I						
	Factory Settings Revert Import Panel Export Panel						
	OK Cancel Apply						

Figure 18. Compiler optimization for the ColdFire V1 CMX Example

8. Compile and download the project into the board. The CMX example works as described in the DEMOJM Lab Supplement for the 32-bit Flexis JM128 document. Hold down the PTG0 button while pressing and releasing the Reset button to enter bootloader mode. The bootloader drive appears in the PC. Copy another application's S19 file onto the drive to see the application change. For example, use either the ColdFire V1 S19 file in the Bootloader directory \S19 Files. Enter bootloader mode again, and copy the CMX example S19 file back to the board using the file \usb-peripheral\projects\CodeWarrior-6.x\mcf51xx\hid-demo\bin\hid_demo.abs.S19.



4.6 Adding the Bootloader to the Existing MC9S08 Project

This section gives step-by-step instructions on how to take an existing MC9S08 CodeWarrior project and add the bootloader. This example uses the HID-DEMO from CMX for the MC9S08 with the complimentary CMX USB stack. For licensing reasons, the CMX source code is not included with this application note's firmware. However, the steps below give instructions on how to take the CMX example and add the bootloader. The CMX software can be downloaded from Freescale's website at http://www.freescale.com/usb.

The steps below reference directories and files for both the bootloader and CMX example. The bootloader files and paths are referenced from the root directory of this application note's firmware. The CMX example files and paths are referenced from the root directory of the CMX software installation.

1. Copy the following files from the bootloader project into the application project:

 File

 From: \Shared Source\S08_Source\S08_Bootloader.abs.s19

 To: \usb-peripheral\projects\CodeWarrior\hc9S08jm60\hid-demo\Sources

 From: \Shared Source\S08_Source\Bootloader_S08.h

 To: \usb-peripheral\projects\CodeWarrior\hc9S08jm60\hid-demo\Sources\

- 2. Copy/Edit the PRM linker file. The PRM file is critical when integrating the bootloader with an application. The bootloader PRM file must be used as the template for the new application PRM file. However, modifications may be required based on the application. The existing application's PRM file needs to be well understood. For more information on linker files, please read the *CodeWarrior Build Tools Utilities Manual*. Pay attention to the SEGMENTS and PLACEMENT sections, and STACK settings of the existing PRM file. For this CMX example, do the following steps:
 - a) Copy the PRM file from the bootloader application project into the application project overwriting the existing file:

File

 From:
 \S08 USB Bootloader Projects

 \Application with Bootloader S08 Blinks PTE2\prm\Project.prm

 To:
 \usb-peripheral\projects\CodeWarrior\hc9S08jm60\hid-demo\prm\Project.prm

b) Modify the stack size. The bootloader was written with a stack size of 80 (0x50) bytes, which is the default stack size for a CodeWarrior project. However, the CMX example requires 144 (0x90) bytes. Change the following lines in the PRM file:

MY_STACK		=	READ	WRITE	0x1020	ТО	0x10AF;
Application	RAM	=	READ	WRITE	0x0100	ТО	0x101F;


- c) The full source of the new PRM file is in Appendix G, "PRM File for the MC9S08 CMX Example," on page 66.
- 3. Modify the main application file to integrate with the bootloader. For this CMX example, modify hid_main.c with the following:
 - a) Include the Bootloader_S08.h header file in the main application file. Add the following line to hid main.c:

```
#include "Bootloader_S08.h"
```

b) Add the user entry jump vector to the main application file. For this CMX example, the user entry point is _Startup(). Add the following lines to hid_main.c:

```
void _Startup(void);
// User Application code entry
volatile const JumpVect UsrEntry@ USER_ENTRY_ADDRESS = {
    0xCC,    // op-code for JMP
    _Startup
};
```

c) Add the re-directed interrupt vector table, and point the re-directed vectors to the application's interrupt service routines. In this CMX example, only the USB interrupt is used. Add the following lines to the hid_main.c file:

```
interrupt void Dummy ISR(void) {}
// User Interrupt Jump Vector Table
volatile const JumpVect UserJumpVectors [InterruptVectorsNum] @
VectorAddressTableAddress = {
   { 0xCC, Dummy ISR}, // 29 - RTC
                       // 28 - IIC
    { 0xCC, Dummy ISR},
                       // 27 - ACMP
   { 0xCC, Dummy ISR},
                        // 26 - ADC Conversion
   { 0xCC, Dummy ISR},
                        // 25 – KBI
   { 0xCC, Dummy ISR},
   { 0xCC, Dummy_ISR},
                        // 24 - SCI2 Transmit
                       // 23 - SCI2 Receive
    { 0xCC, Dummy ISR},
                         // 22 - SCI2 Error
    { 0xCC, Dummy_ISR},
                       // 21 - SCI1 Transmit
   { 0xCC, Dummy_ISR},
   { 0xCC, Dummy ISR}, // 20 - SCI1 Receive
   { 0xCC, Dummy ISR},
                         // 19 - SCI1 Error
                         // 18 - TPM2 Overflow
   { 0xCC, Dummy ISR},
    { 0xCC, Dummy ISR},
                         // 17 - TPM2 Channel1
   { 0xCC, Dummy ISR},
                       // 16 - TPM2 Channel0
   { 0xCC, Dummy_ISR},
                       // 15 - TPM1 Overflow
                        // 14 - TPM1 Channel5
    { 0xCC, Dummy ISR},
                        // 13 - TPM1 Channel4
    { 0xCC, Dummy ISR},
                         // 12 - TPM1 Channel3
    { 0xCC, Dummy ISR},
                         // 11 - TPM1 Channel2
    { 0xCC, Dummy ISR},
                         // 10 - TPM1 Channel1
   { 0xCC, Dummy ISR},
                         // 9 - TPM1 Channel0
   { 0xCC, Dummy_ISR},
                         // 8 - Reserved
   { 0xCC, Dummy ISR},
    { 0xCC, usb it handler}, // 7 - USB Status
    { 0xCC, Dummy ISR}, // 6 - SPI2
                        // 5 - SPI1
    { 0xCC, Dummy ISR},
                        // 4 - MCG Loss Lock
    { 0xCC, Dummy ISR},
                       // 3 - Low VoltDetect
   { 0xCC, Dummy ISR},
    { 0xCC, Dummy ISR},
                        // 2 - IRO
```

Using the Bootloader

```
{ 0xCC, Dummy_ISR}, // 1 - SWI
};
```

- d) Because several changes were made to the hid_main.c file, Appendix H, "hid_main.c for the MC9S08 CMX Example," on page 69 provides the source code for the entire file.
- 4. Remove any references to a reset vector in the application. The bootloader uses the reset vector to point to its start-up function that determines if bootloader or application mode must start. If the application keeps a reset vector reference, this can cause an error because two vectors attempt to use the same location.

A common method in CodeWarrior to set the reset vector is to declare the vector in the PRM file. The PRM file shows a reference like VECTOR 0 _Startup. This reference must be removed.

Another common method for the reset vector is to provide a constant vector table in a project file, for example Vectors.c. This vector table is forced to the proper flash location for the vectors either by using a fixed address in the vector table declaration, or by using a segment declared in the PRM file. For the bootloader, this vector table must be removed. Interrupts are re-directed in the steps below.

5. Change the existing interrupt vector table. The existing application places the interrupt vector table in the protected bootloader flash memory. These vectors need to be re-directed. The first step is to change references in the application to the existing interrupt service routines.

If an interrupt vector number is used when the ISR is declared, CodeWarrior loads that interrupt vector with the address of the declared ISR. With the bootloader, these interrupt vector numbers need to be removed from the ISR declaration.

Another common method for vector tables is to provide a constant vector table in a project file, for example Vectors.c. This vector table is forced to the proper flash location for the vectors either by using a fixed address in the vector table declaration, or by using a segment declared in the PRM file. For the bootloader, this vector table must be removed.

For this CMX example, the only interrupt used is the USB interrupt. The interrupt vector number of the usb_it_handler ISR declaration needs to be removed. Change the line below in usb.c to the following

```
interrupt 7 void usb_it_handler(void)
to
interrupt void usb it handler(void)
```

6. Compile and download the project into the board. The CMX example works as described in the DEMOJM Lab Supplement for the 8-bit Flexis JM60 document. Hold down the PTG0 button while pressing and releasing the Reset button to enter bootloader mode. The bootloader drive appears in the PC. Copy another application's S19 file onto the drive to see the application change. For example, use either MC9S08 S19 file in the Bootloader directory \S19 Files. Enter the bootloader mode again, and copy the CMX example S19 file back to the board using the file \usb-peripheral\projects\CodeWarrior\hc9S08jm60\hid-demo\bin\ Project.abs.s19.



4.7 Porting the Bootloader to Another Freescale Device

This bootloader was written for the three specified parts because they share the same USB peripheral registers and functionality for USB device. At the time this application note was written, the Freescale microcontrollers that share this peripheral include the Flexis JM family of MC9S08 and ColdFire V1 devices, the ColdFire V2 devices with part numbers MCF522xx, and the MC9S08JS family. Future Freescale devices are also planned with this same USB peripheral.

This application note provides the firmware for the three specified devices. However, the firmware can easily be ported to any of these devices sharing the same USB peripheral. When porting to these devices, pay particular attention to the items below:

- Change the macros defining the memory map in Bootloader_xx.h (i.e. Bootloader_V2.h). These macros define the flash and RAM address range of the part, where the flash protection range starts, where the User Entry jump vector is located, the flash page size, and address range for the USB buffers.
- Change the Linker file for the new part. Read the linker manual to understand the linker file. Then modify the linker file for the new memory map.
- Check the interrupts for the new part. Adjust the true interrupt vector table and the re-directed interrupt vector table for the new part.
- Verify part initialization in Bootloader_xx.c and in usr_entry_xx.c, including clock initialization, and flash clock initialization.
- As needed, change the forced entry method into bootloader mode in usr_entry_xx.c. For example, change the pin that is used during reset to enter bootloader mode.
- Verify the Flash Protection registers. For the MC9S08 and ColdFire V1, change the NVPROT register value in Bootloader_xx.c. For the ColdFire V2, change the CFMPROT register in mcf5225x_vectors.s.

5 Troubleshooting

The firmware provided has been thoroughly tested using the combination of devices, boards, and operating systems listed in Section 1, "Introduction," on page 1. However, if the bootloader is modified or ported to another device, below is a list of common issues:

5.1 Reset Vector

If neither the bootloader nor the application start, the reset vector is likely to be responsible. To test it, use the debugger and place a breakpoint at the beginning of _Entry() in usr_entry_xx.c. Then reset the device holding the button to force bootloader mode. If the debugger hits this breakpoint, the reset vector is valid. If it does not hit this point, verify the reset vector points to _Entry(). The reset vector must be controlled by the bootloader.

5.2 User Entry Vector

If the bootloader executes as expected but the application never starts, the User Entry Vector is likely to be responsible. To test this, use the debugger and place a breakpoint in _Entry() in usr_entry_xx.c where



Troubleshooting

the bootloader jumps to the User Entry vector. Hold the button and reset to force the bootloader mode. Run to the breakpoint, then single-step through to see if the bootloader successfully jumps to the application. After the breakpoint, the bootloader must jump to the User Entry vector located at a specific absolute address in the flash. At that address is another JMP instruction that must jump to the application entry point.

If the bootloader initially jumps to the wrong absolute address, ensure the macro

USER_ENTRY_ADDRESS in bootloader_xx.h is the correct address. If the vector is located at the correct absolute address and it jumps to the wrong address for the application entry, ensure the application loads the User Entry vector properly. In the provided bootloader examples, this is executed in main.c. The vector needs to be loaded properly in the application load. The bootloader code does not load this vector.

5.3 Interrupts

Re-directing the interrupt vectors is critical for the application to work properly. If the application starts properly, but does not function properly, interrupts are likely to be responsible. This is especially evident if the application worked fine before integrating with the bootloader. Symptoms of interrupt issues include the application code starting correctly but running away intermittently. To verify, disable interrupts and test if the application executes without running away.

If it is an interrupt issue, there are two aspects of the re-directed interrupt vectors to verify. First, the application is responsible for loading the interrupt vectors in the re-directed interrupt vector table. Please read Section Section 4.3, "Creating a New Project with the Bootloader," on page 20 to understand how the application loads the re-directed interrupt vector table.

The second issue is to verify that the interrupt vectors have been re-directed. For devices that re-direct to RAM, ensure the VBR register is set in the application to point to RAM. For the devices that re-direct to the flash, ensure the vectors in the default interrupt vector location point to the re-directed vector. In the MC9S08, this re-direction is executed in the file Redirect_Vectors_S08.c.

5.4 Bootloader Erases Part of Itself

When modifying the bootloader or porting to a different device, it is possible the bootloader erases part of itself during a firmware update. Symptoms of this issue include the bootloader fails and runs away after the flash erase routine, or the bootloader runs successfully the first time but fails a second time.

There are two possible causes for this issue. The first is the flash protection range does not adequately protect the bootloader code in flash. Please read Section 2.8, "Flash Protection," on page 6 on Flash Protection to ensure the bootloader is properly protected.

The second cause is that cross-calls are occurring, and the bootloader is calling functions in the application space. The application space gets erased during a firmware update, so cross-calling causes an issue. Cross-calling must be avoided. Please read Section 4.1, "Prevent Cross-Calling," on page 16 on cross-calling and how to prevent it.





5.5 Linker Overlap Errors

When modifying the bootloader or porting to a different device, it is possible to get linker overlap errors when linking the project. Here are some possible reasons and solutions:

- Linker file has overlapping segments. When modifying the linker file for a new memory map, verify the segments do not overlap.
- Application, bootloader code, or RAM has outgrown its segment. If the bootloader code size exceeds its segment size, increase the segment size to a flash protection range large enough to protect the bootloader code. Then update for the new memory map as described in Section 4.7, "Porting the Bootloader to Another Freescale Device," on page 39. For other outgrown issues, modify the memory map or move to a larger memory device as described in Section 4.7, "Porting the Bootloader to Another Freescale Device.
- Application interrupt vectors are still declared. If the application still declares an interrupt vector in the default vector table, it conflicts with the bootloader's vector that should be at that location. The application interrupt vector needs to be located in the re-directed vector table. To fix this linker issue, load the application interrupt in the re-directed vector table as described in Section 4.3, "Creating a New Project with the Bootloader," on page 20. Also, ensure the application does not reference the interrupt service routine in the default interrupt vector table that is controlled by the bootloader. These references include declaring the interrupt service routine with the interrupt vector number as shown below. A vector table is also included with the application that loads the default interrupt vector table and points to the ISRs.

interrupt VectorNumber_Vftm2ovf void timer(void) {

The code above is an example of how to declare an interrupt service routine in CodeWarrior. This declaration tells the linker to load the default vector table at the vector number with the vector to the ISR. In this case, VectorNumber_Vftm2ovf is a macro specifying the vector number and timer is the ISR function name. These vector numbers in the ISR declaration need to be removed because they overlap with the bootloader vector table.

• Application reset vector is still declared. If the application still declares the reset vector, it conflicts with the bootloader's vector that should be at that location. To fix this linker issue, ensure the application does not reference the application entry point in the reset vector that is controlled by the bootloader. These references include specifying the application entry point in the linker file as shown below. A vector table is also included with the application that loads the reset vector and points to the application.

VECTOR 0 _Startup

The code above is an example of how to declare the reset vector in an MC9S08 PRM file in CodeWarrior. This command tells the linker to load the reset vector with the vector _Startup. In this case, _Startup() is the application entry point function. This reset vector declaration needs to be removed because it overlaps with the bootloader reset vector.

• Compiler optimization settings. It is possible when integrating an application using the bootloader library that the bootloader compile into binary code larger than the linker segment for the bootloader code. This can occur because the application project uses less optimization for the compiler than the original bootloader project. Change the compiler optimization settings to force the bootloader to fit in the protected flash segment, or change the memory map as described in Section 4.7, "Porting the Bootloader to Another Freescale Device," on page 39.



Conclusion

5.6 USB Drive does not Appear in the Host

If the USB cable is connected between the host computer and the device the USB drive must then be visible in the host a few seconds after entering bootloader mode. If not, ensure the device is properly powered and connected. Also, ensure the hardware is configured for USB device operation similar to the default jumper settings of the demo board. Refresh the host application to check for the new drive. In Windows, check the Device Manager to see if the USB device has enumerated properly. Check that the bootloader starts properly as described in Section 5.1, "Reset Vector," on page 39. Check that the bootloader has not corrupted itself as described in Section 5.4, "Bootloader Erases Part of Itself," on page 40. Reboot the host computer. If none of these solutions appear to fix the issue, use the debugger or a USB analyzer to debug the USB enumeration to see where the issue occurs.

5.7 Bootloader Status Error before a File Transfer

After the bootloader drive enumerates in the host computer, the drive shows the READY.TXT file. Ensure this file is visible before transferring an S19 file to the drive. If there is already an error status file in the drive before transferring any file, this can be caused by settings within the host operating system. For example, Macintosh computers can try to write a file to removable drives after the drive enumerates. The bootloader assumes any file written to the root directory is an S19 file, and starts parsing the file. If a file other than an S-record file is written to the bootloader drive, it will cause errors. To fix this change the operating system settings to prevent it from writing files itself to the drive.

5.8 Flash Erase/Program Generates Errors

If the status file FFAILED.TXT is present in the bootloader drive after a firmware update attempt, this signals there was an error in erasing or programming part of the flash. This error is usually caused because an invalid flash address is erased/programmed, or the flash clock is not in the specified frequency range. Verify the memory map as described in Section 4.7, "Porting the Bootloader to Another Freescale Device," on page 39. Also, verify the flash clock divider in Bootloader_Main() in Bootloader_xx.c. If the issue continues to persist, use the debugger with breakpoints to see at what point the error occurs, and verify the flash address received by the bootloader.

5.9 Bootloader and Application Cross-Call Issues

Cross-calling between the bootloader and application is hazardous. It can cause symptoms including the bootloader corrupting itself after a firmware update, or a new application fails to work when updated on a device with an older revision of the bootloader. Please refer to Section 4.1, "Prevent Cross-Calling," on page 16 to prevent cross-calling.

6 Conclusion

Freescale's USB Mass Storage Device bootloader allows for very easy firmware updates. It does not require a driver, does not require any software on the host computer, and can be executed by anyone. This bootloader also works with a broad selection of Freescale microcontrollers. The information in this application note allows any application to be integrated with the bootloader.



Appendix A mcf5222x_vectors.s for the Coldfire V2 CMX Example

Section 4.4, "Adding the Bootloader to the Existing ColdFireV2 Project," on page 24 gives detailed steps to start with the ColdFire V2 CMX Example and add the bootloader. The mcf5222x_vectors.s file required several modifications for this project. Below is the text used for the new mcf5222x_vectors.s file for this example with the bootloader. This file is located at the following path under the CMX Installation root directory:

\usb-peripheral\projects\CodeWarrior\mcf52223\mcf5222x_vectors.s

```
This file contains the vector table and the startup code executed out of
reset.
.global VECTOR TABLE
       .global VECTOR TABLE
       .global start
       .global start
       .global d0 reset
       .global d0 reset
       .global d1 reset
       .global d1 reset
       .extern __IPSBAR
       .extern ___SRAM
       .extern FLASH
       .extern SP INIT
   .extern _irq_handler02
   .extern _irq_handler03
   .extern _
          irq handler04
   .extern _
          irq handler05
   .extern _irq_handler06
   .extern _irq_handler07
   .extern _irq_handler08
   .extern _irq_handler09
   .extern _irq_handler0a
   .extern irq handler0b
   .extern irq handler0c
   .extern irq handler0d
   .extern _irq_handler0e
   .extern irq handler0f
   .extern
          irq handler10
   .extern
          irq handler11
   .extern _irq_handler12
   .extern _irq_handler13
   .extern _irq_handler14
   .extern _irq_handler15
   .extern _irq_handler16
   .extern irq handler17
   .extern irq handler18
   .extern irq handler19
   .extern _irq_handler1a
   .extern irq handler1b
```

.extern irq handler1c



mcf5222x_vectors.s for the Coldfire V2 CMX Example

.extern	ira handler1d
ovtorn	irg handlerle
owtorn	_irg_handlor1f
.extern	_irg_handler20
.extern	_irg_handler20
.extern	_irq_nandler21
.extern	_irq_nandler22
.extern	_irq_handler23
.extern	_irq_handler24
.extern	_irq_handler25
.extern	_irq_handler26
.extern	_irq_handler27
.extern	_irq_handler28
.extern	_irq_handler29
.extern	_irq_handler2a
.extern	_irq_handler2b
.extern	irq handler2c
.extern	irq handler2d
.extern	irg handler2e
.extern	irg handler2f
.extern	irg handler30
.extern	irg handler31
extern	irg_handler32
extern	irg handler33
extern	_irg_handler34
ovtorn	_irg_handler35
ovtorn	_irg_handler36
ovtorn	_irg_handlor37
ovtorn	_irg_handler?
.extern	_irg_handler30
.extern	_irg_handler3a
.extern	_irg_handler3h
.extern	_irg_handler3c
.extern	_irg_handler3d
.extern	_irg_handler2e
.extern	_irg_handler3e
.extern	_irq_nandler31
.extern	_irq_nandler40
.extern	_irq_handler41
.extern	_irq_handler42
.extern	_irq_handler43
.extern	_irq_handler44
.extern	_irq_handler45
.extern	_irq_handler46
.extern	_irq_handler47
.extern	_irq_handler48
.extern	_irq_handler49
.extern	_irq_handler4a
.extern	_irq_handler4b
.extern	_irq_handler4c
.extern	_irq_handler4d
.extern	_irq_handler4e
.extern	_irq_handler4f
.extern	_irq_handler50
.extern	_irq_handler51
.extern	irq handler52
extern	
·CRECTI	irq_handler53
.extern	irq_handler53 _irq_handler54



mcf5222x_vectors.s for the Coldfire V2 CMX Example

.extern	irg handler56
.extern	irg handler57
.extern	irg handler58
.extern	irg handler59
.extern	irg handler5a
.extern	irg handler5b
.extern	irg handler5c
.extern	irg handler5d
.extern	irq handler5e
.extern	irq handler5f
.extern	_irq_handler60
.extern	_irq_handler61
.extern	_irq_handler62
.extern	_irq_handler63
.extern	_irq_handler64
.extern	_irq_handler65
.extern	_irq_handler66
.extern	_irq_handler67
.extern	_irq_handler68
.extern	_irq_handler69
.extern	_irq_handler6a
.extern	_irq_handler6b
.extern	_irq_handler6c
.extern	_irq_handler6d
.extern	_irq_handler6e
.extern	_irq_handler6f
.extern	_irq_handler70
.extern	_irq_handler71
.extern	_irq_handler72
.extern	_irq_handler73
.extern	_irq_handler74
.extern	_irq_handler75
.extern	_irq_handler76
.extern	_irq_handler77
.extern	_irq_handler78
.extern	_irq_handler79
.extern	_irq_handler7a
.extern	_irq_handler7b
.extern	_irq_handler7c
.extern	_irq_handler7d
.extern	_irq_handler7e
.extern	_irq_handler7f
.extern	_low_level_init
.extern	_usb_it_handler
.extern	_uart_it_handler
.extern	_main
.b	SS
d0_reset:	
_d0_reset:.	long 0
dl_reset:	
_dl_reset:.	long U
1	~t
.te	ext
· · · · · · · · · · · · · · · · · · ·	*****
/ ^ ^ ^ ^ ^ * * * * * *	~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~~
_start:	Save off reset values of D^0 and $D^1 * /$
/ ^	Save off teset values of no alia nt ^/

```
NP
```

```
mcf5222x_vectors.s for the Coldfire V2 CMX Example
```

```
move.l d0,d6
move.l d1,d7
/* Initialize RAMBAR1: locate SRAM and validate it */
move.l # SRAM, d0
        #0x21,d0
add.l
        d0,RAMBAR1
movec
/* Locate Stack Pointer */
move.l #__SP_INIT, sp
/* Initialize IPSBAR */
move.l #__IPSBAR,d0
        #0x1,d0
add.l
move.1 d0,0x4000000
/* Initialize FLASHBAR */
/* Flash at address 0x0. */
        #0,d0
move.l
add.1 #0x61,d0
movec
      d0,RAMBAR0
/* Locate Stack Pointer */
move.l #__SP_INIT, sp
/* Save off intial D0 and D1 to RAM */
move.l d6,d0 reset
move.l
        d7,d1_reset
/* Common startup code */
        _low_level_init
jsr
/* Jump to the main process */
                 _main
jsr
bra
nop
nop
halt
.end
```



Appendix B LCF File for ColdFire V2 CMX Example

Section 4.4, "Adding the Bootloader to the Existing ColdFireV2 Project," on page 24 gives detailed steps to start with the ColdFire V2 CMX Example and add the bootloader. The LCF file for this project required several modifications. Below is the text used for this example for the new LCF file with the bootloader. This LCF file is located at the following path under the CMX Installation root directory:

\usb-peripheral\projects\CodeWarrior\mcf52223\m522x evb flash.lcf

```
#*
#*
   (c) copyright Freescale Semiconductor 2008
   ALL RIGHTS RESERVED
#*
#*
   File Name: mcf52259 bl flash.lcf
#*
#*
#*
   Purpose: This file is for a USB Mass-Storage Device bootloader. This file
#*
           is the linker command file for the flash target.
#*
#*
   Assembler: Codewarrior for ColdFire V7.1
#*
#*
   Version: 1.1
#*
#*
   Author: Derek Snell
#*
#*
#*
   Location: Indianapolis, IN. USA
#*
#* UPDATED HISTORY:
#*
#* REV
       YYYY.MM.DD AUTHOR
                               DESCRIPTION OF CHANGE
#* ---
        _____ _
                                _____
#* 1.0
        2008.06.10 Derek SnellInitial version
#* 1.1
        2009.06.01 Derek SnellImproved for easier application integration
#*
#*
#/* Freescale is not obligated to provide any support, upgrades or new */
\#/* releases of the Software. Freescale may make changes to the Software at */
\#/* any time, without any obligation to notify or provide updated versions of */
#/* the Software to you. Freescale expressly disclaims any warranty for the */
\#/* Software. The Software is provided as is, without warranty of any kind, */
#/* either express or implied, including, without limitation, the implied */
#/* warranties of merchantability, fitness for a particular purpose, or */
\#/* non-infringement. You assume the entire risk arising out of the use or */
\#/* performance of the Software, or any systems you design using the software */
\#/* (if any). Nothing may be construed as a warranty or representation by */
\#/* Freescale that the Software or any derivative work developed with or */
\#/* incorporating the Software will be free from infringement of the */
#/* intellectual property rights of third parties. In no event will Freescale */
\#/* be liable, whether in contract, tort, or otherwise, for any incidental, */
#/* special, indirect, consequential or punitive damages, including, but not */
\#/* limited to, damages for any loss of use, loss of time, inconvenience, */
#/* commercial loss, or lost profits, savings, or revenues to the full extent */
\#/* such may be disclaimed by law. The Software is not fault tolerant and is */
\#/* not designed, manufactured or intended by Freescale for incorporation */
```

LCF File for ColdFire V2 CMX Example

```
#/* into products intended for use or resale in on-line control equipment in */
#/* hazardous, dangerous to life or potentially life-threatening environments */
\#/* requiring fail-safe performance, such as in the operation of nuclear */
#/* facilities, aircraft navigation or communication systems, air traffic */
\#/* control, direct life support machines or weapons systems, in which the */
\#/* failure of products could lead directly to death, personal injury or */
\#/* severe physical or environmental damage (High Risk Activities). You */
\#/* specifically represent and warrant that you will not use the Software or */
#/* any derivative work of the Software for High Risk Activities. ^{*/}
#/* Freescale and the Freescale logos are registered trademarks of Freescale */
#/* Semiconductor Inc.
                                                                       */
MEMORY
{
        vectorflash(RX) : ORIGIN = 0x00000000, LENGTH = 0x00000418
        bootcode (RX): ORIGIN = 0x00000420, LENGTH = 0x00003BE0
        #flash (RX) : ORIGIN = 0x00000420, LENGTH = 0x0007FC00
        flash (RX) : ORIGIN = 0x00004010, LENGTH = 0x0007BFF0
        vectorram(RWX) : ORIGIN = 0x20000000, LENGTH = 0x00000400
                       (RWX) : ORIGIN = 0x20000400, LENGTH = 0x0000FC00
        ram
        bootsram(RWX) : ORIGIN = 0x20000600, LENGTH = 0x0000FA00
        ipsbar (RWX) : ORIGIN = 0x40000000, LENGTH = 0x0
}
SECTIONS
{
        ___SRAM SIZE
                      = SIZEOF(ram);
        SRAM SIZE
                       = ___SRAM_SIZE;
        FLASH SIZE
                        = SIZEOF(flash);
         __FLASH_SIZE
                       = FLASH SIZE;
         FLASHBAR SIZE = 0 \times 00080000;
        ____RAMBAR SIZE
                        = 0x0000FFFF;
        .ipsbar :
        {
                 IPSBAR
                               = .;
                 IPSBAR
                               = .;
        } > ipsbar
        .vectorflash :
        {
                  FLASHBAR
                               = .;
         FLASH
                                = .;
                 = .;
          FLASH
              mcf5225x_vectors.s(.text)
        } > vectorflash
        .vectorram :
        {
                  RAMBAR
                               = .;
                SRAM
                               = .;
                  SRAM
                                        = SRAM;
                  VECTOR RAM = .;
        } > vectorram
```

```
.bootcode: {
             Boot START= .;
             usr_entry_V2.c (.text)
             usr_entry_V2.c (.rodata)
             V2 Bootloader.lib (.text)
             V2_Bootloader.lib (.rodata)
              = ALIGN (0x4); 
              Boot_END
                             = .;
    } > bootcode
    .bootsram: {
             ___Boot_RAM_START= .;
             usr_entry_V2.c (.bss)
             V2_Bootloader.lib(.bss)
             . = ALIGN (0x4);
             Boot RAM END= .;
    } > bootsram
/* Constant objects. */
    .flash :
    {
             *(.text)
             *(.rodata)
                                       = ALIGN(0 \times 10);
              __COPY_START
                             = .;
              DATA ROM
                             = .;
             ___DATA_ROM
                             = .;
              ROM AT
                              = .;
    } > flash
/* Inicialised data. This needs to be copied to RAM runtime. It will be
   allocated after .flash. */
    .data : AT(___COPY_START)
    {
                            = ALIGN(0x10);
              COPY_DST
                            = .;
              DATA RAM
                         = .;
             ___DATA_RAM
                            = .;
             sinit
                             = .;
             STATICINIT
             *(.data)
    *(.relocate_code)
                           = ALIGN (0 \times 10);
             ____DATA_END
                          = .;
              _____START_SDATA = .;
             *(.sdata)
             ___COPY_END
                             = .;
                             = .;
              DATA END
             ___SDA_BASE
                             = .;
                                       = ALIGN(512);
    } > ram
    .bss :
    {
                            = ALIGN(4);
               BSS_START
                             = .;
```

LCF File for ColdFire V2 CMX Example

```
BSS START
                            = .;
         ___START_SBSS
                           = .;
           ZERO START
                            = .;
         *(.sbss)
         * (SCOMMON)
         __END_SBSS
                            = .;
          START_BSS
                            = .;
         *(.bss)
         * (COMMON)
           ZERO END
                            = .;
         __END_BSS
                            = .;
         ___BSS END
                            = .;
          BSS END
                            = .;
/* Buffer descriptor base address
  shall be aligned to 512 byte boundary.
  Size shall be 512 bytes. */
                  = ALIGN(512);
 BDT BASE= .;
                = . + 512;
 BDT END
                = .;
         ____SP_SIZE
                          = 0 \times 0800;
         ___SP_SIZE
                           = ____SP_SIZE;
= ____RAMBAR + ____RAMBAR_SIZE + 1 - ____SP_SIZE;
         ____SP_END
          SP END
                            = ____SP_END;
          SP_INIT
                           = ____SP_END + ____SP_SIZE;
         __SP INIT
                           = ____SP_INIT;
           __SP_AFTER_RESET = ___RAMBAR + ___RAMBAR_SIZE - 4;
} >> ram
romp at = ROM AT + SIZEOF(.data);
.romp : AT (_romp_at)
{
           _S_romp = _romp_at;
         WRITEW (____ROM_AT);
         WRITEW(ADDR(.data));
         WRITEW(SIZEOF(.data));
         WRITEW(0);
         WRITEW(0);
         WRITEW(0);
}
```

}



Appendix C hid_main.c for ColdFire V2 CMX Example

Section 4.4, "Adding the Bootloader to the Existing ColdFireV2 Project," on page 24 gives detailed steps to start with the ColdFire V2 CMX Example and add the bootloader. The hid_main.c file for this project required several modifications. Below is the text used for the new hid_main.c file for this example with the bootloader. This file is located at the following path under the CMX Installation root directory:

```
\usb-peripheral\src\mcf5222x\hid-demo\hid main.c
```

```
Copyright (c) 2006-2007 by CMX Systems, Inc.
 This software is copyrighted by and is the sole property of
* CMX. All rights, title, ownership, or other interests
* in the software remain the property of CMX. This
* software may only be used in accordance with the corresponding
* license agreement. Any unauthorized use, duplication, transmission,
* distribution, or disclosure of this software is expressly forbidden.
* This Copyright notice may not be removed or modified without prior
* written consent of CMX.
* CMX reserves the right to modify this software without notice.
* CMX Systems, Inc.
* 12276 San Jose Blvd. #511
* Jacksonville, FL 32223
* USA
* Tel: (904) 880-1840
* Fax: (904) 880-1632
* http: www.cmx.com
* email: cmx@cmx.com
#include "usb-drv/usb.h"
#include "target.h"
#include "hid mouse.h"
#include "hid kbd.h"
#include "hid generic.h"
/* none */
*****
/* none */
/* none */
```

NP

hid_main.c for ColdFire V2 CMX Example

```
***************************** Module variables ***********************************
/* none */
// Added for Bootloader
#include "Bootloader V2.h"
extern asm void start(void);
void usb it handler(void);
const byte UserEntry[] @ USER ENTRY ADDRESS = {
 0x4E,
 0x71,
 0x4E,
 0xF9
             //asm NOP(0x4E71), asm JMP(0x4EF9)
};
void (* const UserEntry2[])()@(USER ENTRY ADDRESS+4) = {
 start,
};
int main()
{
 hcc_u8 tmp;
 // Add redirected USB interrupt vector to RAM
 __VECTOR_RAM[64 + 53] = (hcc_u32) usb_it_handler;
 hw_init();
 // Re-Direct interrupt vectors to RAM
 mcf5xxx_wr_vbr((hcc_u32) __VECTOR_RAM);
 Usb Vbus Off();
 /* See in what mode should we run. */
 tmp = (hcc u8) (SW1 ACTIVE() ? 1 : 0);
 tmp |= (hcc_u8)(SW2_ACTIVE() ? 2 : 0);
 /* Start the right HID application. */
 switch(tmp)
 {
 case 0:
 default:
  usb cfg init();
   set mode(dm mouse);
  (void)hid mouse();
  break;
 case 1:
  usb_cfg_init();
   set mode(dm kbd);
  hid kbd();
```



hid_main.c for ColdFire V2 CMX Example



usr_entry_V2.c for ColdFire V2 CMX Example

Appendix D usr_entry_V2.c for ColdFire V2 CMX Example

Section 4.4, "Adding the Bootloader to the Existing ColdFireV2 Project," on page 24 gives detailed steps to start with the ColdFire V2 CMX Example and add the bootloader. The usr_entry_V2.c file for this project required several modifications. Below is the text used for the new usr_entry_V2.c file for this example with the bootloader. This file is located at the following path under the CMX Installation root directory:

\usb-peripheral\src\mcf5222x\hid-demo\usr entry V2.c

```
*
*
  (c) copyright Freescale Semiconductor 2008
  ALL RIGHTS RESERVED
*
  File Name: usr entry.c
*
  Purpose: This file is for a USB Mass-Storage Device bootloader. This file
           is the initial entry point for the bootloader
  Assembler: Codewarrior for ColdFire V7.0
  Version: 1.3
  Author: Derek Snell
  Location: Indianapolis, IN. USA
*
 UPDATED HISTORY:
*
 REV
       YYYY.MM.DD AUTHOR
                             DESCRIPTION OF CHANGE
 ___
* 1.0
       2008.06.10 Derek Snell
                             Initial version
* 1.1
       2008.06.30 Derek SnellPorted from JM128
* 1.2
       2008.09.25David Seymour Fixed jump vector in RAM target
* 1.3
       2008.09.26Derek SnellAdded check for User entry vector in flash
/* Freescale is not obligated to provide any support, upgrades or new */
/* releases of the Software. Freescale may make changes to the Software at */
/* any time, without any obligation to notify or provide updated versions of */
/* the Software to you. Freescale expressly disclaims any warranty for the ^{\prime\prime}
/* Software. The Software is provided as is, without warranty of any kind, */
/* either express or implied, including, without limitation, the implied */
/* warranties of merchantability, fitness for a particular purpose, or */
/* non-infringement. You assume the entire risk arising out of the use or */
/* performance of the Software, or any systems you design using the software */
/* (if any). Nothing may be construed as a warranty or representation by */
/* Freescale that the Software or any derivative work developed with or */
/* incorporating the Software will be free from infringement of the */
/* intellectual property rights of third parties. In no event will Freescale */
/* be liable, whether in contract, tort, or otherwise, for any incidental, */
/* special, indirect, consequential or punitive damages, including, but not */
```



usr_entry_V2.c for ColdFire V2 CMX Example

```
/* limited to, damages for any loss of use, loss of time, inconvenience, */
/* commercial loss, or lost profits, savings, or revenues to the full extent ^{\prime}
/* such may be disclaimed by law. The Software is not fault tolerant and is */
/* not designed, manufactured or intended by Freescale for incorporation */
/* into products intended for use or resale in on-line control equipment in */
/* hazardous, dangerous to life or potentially life-threatening environments */
/* requiring fail-safe performance, such as in the operation of nuclear */
/* facilities, aircraft navigation or communication systems, air traffic */
/* control, direct life support machines or weapons systems, in which the */
/* failure of products could lead directly to death, personal injury or */
/* severe physical or environmental damage (High Risk Activities). You */
/* specifically represent and warrant that you will not use the Software or */
/* any derivative work of the Software for High Risk Activities.
                                                                   * /
^{\prime \star} Freescale and the Freescale logos are registered trademarks of Freescale ^{\prime \prime}
/* Semiconductor Inc.
                                                                          */
#include "Bootloader V2.h"
#include "mcf5222x reg.h"
extern asm void start(void);
extern byte ___SRAM[];
void Entry(void)
{
 byte i;
 dword* UserEntryCheck;
 MCF GPIO DDRNQ &= ~MCF GPIO DDRNQ DDRNQ5;// PNQ5 as Input
 MCF GPIO PNQPAR &= ~(MCF GPIO PNQPAR PNQPAR5(3));// set PNQ5 as GPIO
  // delay some time for GPIO stable
 for(i=0;i<3;i++) {</pre>
   asm(nop);
  }
  // If SW1 on PORTNQ5 not pressed, jump to user application
 if (MCF GPIO SETNQ & MCF GPIO SETNQ SETNQ5)
  {
        if ((dword) Entry >= (dword) ( SRAM)) // Test to see if running in RAM or Flash
{
asm (JMP start);
                   // jump to user entry
}
else {
                UserEntryCheck = (dword*)USER ENTRY ADDRESS;
                if (*UserEntryCheck == 0x4E714EF9) // check there is a valid jump op-code
                 {
                         UserEntryCheck++;// increment pointer to next long word
                         if (*UserEntryCheck != 0xFFFFFFF) // check there is a valid vector
                         {
                                  asm (JMP USER ENTRY ADDRESS);
                                                                  // jump to user entry
                         }
                 }
        }
  }
```



usr_entry_V2.c for ColdFire V2 CMX Example

```
// Disable Software Watchdog Timer
MCF\_SCM\_CWCR = 0;
// Enable debug
MCF_GPIO_PDDPAR = 0x0F;
MCF_CLOCK_OCLR = 0xC0;
                         //turn on crystal
// delay some time for oscillator stable
for(i=0;i<255;i++) {</pre>
                asm(nop);
}
MCF CLOCK CCLR = 0 \times 00;
                         //switch to crystal
MCF_CLOCK_OCHR = 0x00; //turn off relaxation osc
// Enable on-chip modules to access internal SRAM
MCF\_SCM\_RAMBAR = (0)
       | MCF_SCM_RAMBAR_BA (MIN_RAM1_ADDRESS)
       | MCF_SCM_RAMBAR_BDE);
Bootloader_Main();
```

}



Appendix E LCF File for ColdFire V1 CMX Example

Section 4.5, "Adding Bootloader to the Existing ColdFire V1 Project," on page 29 gives detailed steps to start with the ColdFire V1 CMX Example and add the bootloader. The LCF file for this project required several modifications. Below is the text used for the new LCF file for this example with the bootloader. This LCF file is located at the following path under the CMX Installation root directory:

\usb-peripheral\projects\CodeWarrior-6.x\mcf51xx\hid-demo\prm\Project_flash.lcf

```
# Sample Linker Command File for CodeWarrior for ColdFire MCF51JM128
```

```
# Memory ranges
MEMORY {
  bootcode (RX) : ORIGIN = 0x000410, LENGTH = 0x00001BF0
  code (RX) : ORIGIN = 0x002200, LENGTH = 0x0001DE00
            (RX) : ORIGIN = 0x000410, LENGTH = 0x0001FBF0
  #code
  #userram (RWX) : ORIGIN = 0x800000, LENGTH = 0x00004000
  vectorram (RWX) : ORIGIN = 0x800000, LENGTH = 0x00000200
  userram (RWX) : ORIGIN = 0x800200, LENGTH = 0x00003E00
  bootsram (RWX) : ORIGIN = 0x8006E0, LENGTH = 0x00003B60
}
SECTIONS {
   IPSBAR = 0xFFFF8000;
   VECTOR TABLE BASE = 0;
# Heap and Stack sizes definition
  ____heap size = 0x0000;
   stack size
                = 0 \times 400;
# MCF51JM128 Derivative Memory map definitions from linker command files:
  RAM ADDRESS, ___RAM_SIZE, ___FLASH_ADDRESS, ___FLASH_SIZE linker
# symbols must be defined in the linker command file.
# 16 Kbytes Internal SRAM
     RAM ADDRESS = 0 \times 00800000;
     RAM SIZE
               = 0 \times 00004000;
# 128 KByte Internal Flash Memory
     FLASH ADDRESS = 0 \times 00000000;
    FLASH SIZE
                   = 0 \times 00020000;
  .userram : {} > userram
  .code : {} > code
  .bootcode:
        {
                    Boot START = .;
                 Bootloader V1.c (.text)
                 Bootloader V1.c (.rodata)
                 usr entry V1.c (.text)
                 ParseS19.c
                                 (.text)
                 ParseS19.c
                                 (.rodata)
                 SCSI Process.c (.text)
```

NP

LCF File for ColdFire V1 CMX Example

```
SCSI_Process.c (.rodata)
               FAT16.c
                              (.text)
               FAT16.c
                               (.rodata)
               exceptions.c
                               (.text)
                = ALIGN (0x4); 
                _Boot_END
                            =.;
} > bootcode
.bootsram:
      {
                 __Boot_RAM_START = .;
               Bootloader_V1.c (.bss)
               Bootloader V1.c (.sbss)
               usr_entry_V1.c (.bss)
               usr_entry_V1.c (.sbss)
               ParseS19.c
                                 (.bss)
               ParseS19.c
                                 (.sbss)
               SCSI_Process.c
                                (.bss)
               SCSI Process.c
                                 (.sbss)
               FAT16.c
                                  (.bss)
               FAT16.c
                                  (.sbss)
                = ALIGN (0x4); 
                 Boot RAM END
                                  =.;
} > bootsram
.text :
{
 *(.text)
  = ALIGN (0x4); 
 *(.rodata)
  = ALIGN (0x4); 
 ____ROM_AT = .;
   ___DATA_ROM = .;
} >> code
.data : AT( ROM AT)
{
   DATA RAM = .;
 ______ = ALIGN(0x4);
 *(.exception)
  = ALIGN(0x4); 
  _exception_table_start_ = .;
 EXCEPTION
 __exception_table_end__ = .;
 _____sinit___ = .;
   STATICINIT
 ___START_DATA = .;
 *(.data)
   = ALIGN (0x4); 
 __END_DATA = .;
  ____START_SDATA = .;
```



LCF File for ColdFire V1 CMX Example

```
*(.sdata)
   = ALIGN (0x4); 
  END SDATA = .;
 ____DATA_END = .;
___SDA_BASE = .;
  = ALIGN (0x4);
} >> userram
.bss :
{
 ____BSS_START = .;
   START SBSS = .;
 *(.sbss)
   = ALIGN (0x4); 
 * (SCOMMON)
 __END_SBSS = .;
   _____BSS = .;
 *(.bss)
 = ALIGN (0x4);
  * (COMMON)
 __END_BSS = .;
  ___BSS_END = .;
   = ALIGN(0x4); 
} >> userram
.custom :
{
   HEAP_START
                       = .;
 heap_addr
HEAP_END
                      = ___HEAP_START;
= ___HEAP_START + ___heap_size;
  . = HEAP_END;
    /* Buffer descriptor base address
      shall be aligned to 512 byte boundary.
      Size shall be 512 bytes. */
                         = ALIGN(512);
    BDT BASE
              = .;
                 = . + 512;
  __BDT_END
                 = .;
                     = ____RAM_ADDRESS + ____RAM_SIZE;
   SP INIT
  SP_END
                     = ____SP_INIT - ____stack_size;
} >> userram
                      = ____SP_INIT;
__SP_INIT
                      = ___SP_INIT;
SP AFTER RESET
_romp_at = ___ROM_AT + SIZEOF(.data);
.romp : AT(_romp_at)
{
 __S_romp = _romp_at;
WRITEW(___ROM_AT);
 WRITEW(ADDR(.data));
```



}

LCF File for ColdFire V1 CMX Example

```
WRITEW(SIZEOF(.data));
WRITEW(0);
WRITEW(0);
WRITEW(0);
}
```



Appendix F hid_main.c for the ColdFire V1 CMX Example

Section 4.5, "Adding Bootloader to the Existing ColdFire V1 Project," on page 29 gives detailed steps to start with the ColdFire V1 CMX example and to add the bootloader. The hid_main.c file for this project required several modifications. Below is the text used for the new hid_main.c file for this example with the bootloader. This file is located at the following path under the CMX Installation root directory:

```
\usb-peripheral\src\mcf51xx\hid-demo\hid main.c
```

```
****
                          Copyright (c) 2006-2007 by CMX Systems, Inc.
 This software is copyrighted by and is the sole property of
* CMX. All rights, title, ownership, or other interests
* in the software remain the property of CMX. This
* software may only be used in accordance with the corresponding
* license agreement. Any unauthorized use, duplication, transmission,
* distribution, or disclosure of this software is expressly forbidden.
* This Copyright notice may not be removed or modified without prior
* written consent of CMX.
* CMX reserves the right to modify this software without notice.
* CMX Systems, Inc.
* 12276 San Jose Blvd. #511
* Jacksonville, FL 32223
* USA
* Tel: (904) 880-1840
* Fax: (904) 880-1632
* http: www.cmx.com
* email: cmx@cmx.com
#include "mcf51xx req.h"
#include "../usb-drv/usb.h"
#include "target.h"
#include "hid mouse.h"
#include "hid kbd.h"
#include "hid generic.h"
//#define DEBUG
//#define EVB
/* none */
/* none */
```

NP

hid_main.c for the ColdFire V1 CMX Example

```
/* none */
/* none */
// Added for Bootloader
#include "Bootloader V1.h"
extern asm void startup(void);
const byte UserEntry[] @ USER ENTRY ADDRESS = {
 0x4E,
 0x71,
 0x4E,
 0xF9
            //asm NOP(0x4E71), asm JMP(0x4EF9)
};
void (* const UserEntry2[])()@(USER ENTRY ADDRESS+4) =
{
 startup,
}:
__interrupt void dummy_ISR(void) {}
typedef void (* pFun)(void);
void (* const RAM vector[])()@REDIRECT VECTORS= {
   (pFun) &dummy_ISR,
                        // vector 0 INITSP
   (pFun) &dummy_ISR,
                       // vector 1 INITPC
                       // vector_2 Vaccerr
   (pFun)&dummy ISR,
   (pFun)&dummy ISR,
                       // vector 3 Vadderr
   (pFun)&dummy ISR,
                       // vector 4 Viinstr
   (pFun)&dummy ISR,
                       // vector 5 VReserved5
   (pFun)&dummy_ISR,
                       // vector_6 VReserved6
   (pFun)&dummy ISR,
                       // vector 7 VReserved7
                       // vector_8 Vprviol
   (pFun)&dummy ISR,
                       // vector 9 Vtrace
   (pFun) &dummy_ISR,
   (pFun) &dummy_ISR,
                       // vector_10 Vunilaop
   (pFun)&dummy_ISR,
                       // vector_11 Vunilfop
   (pFun) &dummy_ISR,
                       // vector_12 Vdbgi
   (pFun) &dummy_ISR,
                       // vector_13 VReserved13
   (pFun)&dummy ISR,
                       // vector 14 Vferror
   (pFun)&dummy ISR,
                       // vector 15 VReserved15
   (pFun)&dummy ISR,
                       // vector 16 VReserved16
   (pFun)&dummy ISR,
                       // vector 17 VReserved17
   (pFun)&dummy_ISR,
                       // vector_18 VReserved18
                       // vector 19 VReserved19
   (pFun)&dummy ISR,
                       // vector 20 VReserved20
   (pFun)&dummy ISR,
   (pFun)&dummy ISR,
                        // vector 21 VReserved21
```



(pFun)&dummy_ISR,	//	vector_22	VReserved22
(pFun)&dummy_ISR,	//	vector_23	VReserved23
(pFun)&dummy_ISR,	//	vector_24	Vspuri
(pFun)&dummy_ISR,	//	vector_25	VReserved25
(pFun)&dummy_ISR,	//	vector_26	VReserved26
(pFun)&dummy_ISR,	//	vector_27	VReserved27
(pFun)&dummy_ISR,	//	vector_28	VReserved28
(pFun)&dummy ISR,	11	vector 29	VReserved29
(pFun)&dummy ISR,	11	vector 30	VReserved30
(pFun) & dummy ISR,	11	vector 31	VReserved31
(pFun)&dummy ISR,	11	vector 32	Vtrap0
(pFun)&dummy ISR,	11	vector 33	Vtrap1
(pFun) & dummy ISR,	11	vector 34	Vtrap2
(pFun) & dummy ISR,	11	vector 35	Vtrap3
(pFun) & dummy ISR,	11	vector 36	Vtrap4
(pFun) & dummy ISR,	11	vector 37	Vtrap5
(pFun) & dummy ISR,	11	vector 38	Vtrap6
(pFun) & dummy ISR,	11	vector 39	Vtrap7
(pFun) & dummy ISR,	11	vector 40	Vtrap8
(pFun) & dummy ISR,	11	vector 41	Vtrap9
(pFun) & dummy ISR,	11	vector 42	Vtrap10
(pFun) & dummy ISR,	11	vector 43	Vtrap11
(pFun) & dummy ISR,	11	vector 44	Vtrap12
(pFun) & dummy ISR,	11	vector 45	Vtrap13
(pFun) & dummy ISR,	11	vector 46	Vtrap14
(pFun) & dummy ISR,	11	vector 47	Vtrap15
(pFun) & dummy ISR,	11	vector 48	VReserved48
(pFun) & dummy ISR,	11	vector 49	VReserved49
(pFun) & dummy ISR,	11	vector 50	VReserved50
(pFun) & dummy ISR,	11	vector 51	VReserved51
(pFun) & dummy ISR,	11	vector 52	VReserved52
(pFun) & dummy ISR,	11	vector 53	VReserved53
(pFun) & dummy ISR,	11	vector 54	VReserved54
(pFun) & dummy ISR,	11	vector 55	VReserved55
(pFun) & dummy ISR,	11	vector 56	VReserved56
(pFun) & dummy ISR,	11	vector 57	VReserved57
(pFun) & dummy ISR,	11	vector 58	VReserved58
(pFun) & dummy ISR,	11	vector 59	VReserved59
(pFun) & dummy ISR,	11	vector 60	VReserved60
(pFun) & dummy ISR,	11	vector 61	Vunsinstr
(pFun) & dummy ISR,	11	vector 62	VReserved62
(pFun) & dummy ISR,	11	vector 63	VReserved63
(pFun) & dummy ISR,	11	vector 64	Vira
(pFun) & dummy ISR,	11	vector 65	Vlvd
(pFun) & dummy ISR,	11	vector 66	Vlol
(pFun) & dummy ISR,	11	vector 67	Vspi1
(pFun) & dummy ISR,	11	vector 68	Vspi2
(pFun) & usb it handler.	11	vector 69	Vusb
(pFun) & dummy ISR,	11	vector 70	VReserved70
(pFun) &dummy ISB.	11	vector 71	Vtpm1ch0
(pFun) & dummy ISR,	11	vector 72	Vt.pmlch1
(pFun) & dummy ISR.	//	vector 73	Vt.pm1ch2
(pFun) & dummy ISR.	//	vector 74	Vt.pm1ch3
(pFun) & dummy ISR.	11	vector 75	Vtpm1ch4
(pFun) & dummy ISR	11	vector 76	Vtpm1ch5
(pFun) & dummy ISR	11	vector 77	Vtpmlovf
(pFun) & dummy ISR	11	vector 78	Vtpm2ch0
(<u></u> , <u></u> , <u></u> ,	, ,		p



hid_main.c for the ColdFire V1 CMX Example

```
(pFun)&dummy ISR,
                                           // vector 79 Vtpm2ch1
                                          // vector 80 Vtpm2ovf
     (pFun)&dummy ISR,
     (pFun)&dummy ISR,
                                          // vector 81 Vscilerr
                                          // vector 82 Vscilrx
     (pFun) & dummy ISR,
     (pFun) & dummy ISR,
                                          // vector 83 Vsciltx
     (pFun) & dummy ISR,
                                         // vector 84 Vsci2err
                                          // vector_85 Vsci2rx
     (pFun)&dummy ISR,
                                     // vector_83 vscr2rx
// vector_86 Vscr2tx
// vector_87 Vkeyboard
// vector_88 Vadc
// vector_99 Vacmpx
// vector_90 Viic1x
// vector_91 Vrtc
// vector_92 Viic2x
// vector_93 Vcmt
// vector_94 Vcanwu
// vector_95 Vcanerr
// vector_96 Vcanrx
// vector_98 Vrnga
// vector_99 VReserved99
// vector_100 VReserved100
// vector_101 VReserved101
// vector_103 VReserved103
// vector_104 VL7swi
// vector_105 VL6swi
                                         // vector_86 Vsci2tx
     (pFun)&dummy ISR,
     (pFun)&dummy ISR,
     (pFun) &dummy_ISR,
     (pFun) &dummy_ISR,
     (pFun)&dummy_ISR,
     (pFun) &dummy_ISR,
     (pFun)&dummy ISR,
     (pFun) & dummy ISR,
     (pFun)&dummy ISR,
     (pFun)&dummy ISR,
     (pFun)&dummy ISR,
     (pFun)&dummy ISR,
     (pFun)&dummy ISR,
     (pFun)&dummy ISR,
     (pFun)&dummy_ISR,
     (pFun)&dummy_ISR,
     (pFun)&dummy_ISR,
     (pFun) &dummy_ISR,
                                         // vector 104 VL7swi
     (pFun)&dummy ISR,
     (pFun)&dummy ISR,
                                         // vector 105 VL6swi
     (pFun)&dummy ISR,
                                         // vector 106 VL5swi
     (pFun)&dummy ISR,
                                         // vector 107 VL4swi
     (pFun)&dummy_ISR,
                                         // vector 108 VL3swi
                                          // vector 109 VL2swi
     (pFun) & dummy ISR,
                                           // vector 110 VL1swi
     (pFun)&dummy ISR,
};
#ifdef ON THE GO
/* If on-the-go is used pull-up control is done by the on-the-go driver.
   To avoid having trouble this callback must be empty. */
void enable usb pull up(void)
{
}
#else
void enable_usb_pull_up(void)
{
 USB OTG CONTROL |= USB OTG CONTROL DPPULLUP NONOTG MASK;
 // enable pullup in non-otg mode by setting bit 4
 USBTRCO USBPU = 1;
}
#endif
int main()
{
  hcc u8 tmp;
  /* !! This section needs to be here to redirect interrupt vectors !! */
  dword *pdst,*psrc;
  byte i;
```



hid_main.c for the ColdFire V1 CMX Example

```
asm (move.l #0x00800000,d0);
 asm (movec d0,vbr);
 pdst=(dword*)0x00800000;
 psrc=(dword*)&RAM_vector;
 for (i=0;i<111;i++,pdst++,psrc++)</pre>
 {
   *pdst=*psrc;
 }
 /* !! Start application code below here !! */
 stack init(0x88);
 hw init();
 usb_init(); /* select MCGPLLSCK clock as the source clock
 /* See in what mode should we run. */
 tmp = (hcc u8)(SW1 ACTIVE() ? 1 : 0);
 tmp |= (hcc_u8)(SW2_ACTIVE() ? 2 : 0);
 /* Start the right HID application. */
 switch(tmp)
 {
 case 0:
 default:
   set mode(dm mouse);
   hid mouse();
   break;
 case 1:
   set mode(dm kbd);
   hid kbd();
   break;
 case 2:
   set_mode(dm_generic);
   hid_generic();
   break;
 }
 /* We will never get here. */
 return 0;
}
```



PRM File for the MC9S08 CMX Example

Appendix G PRM File for the MC9S08 CMX Example

Section 4.6, "Adding the Bootloader to the Existing MC9S08 Project," on page 36 gives detailed steps to start with the MC9S08 CMX Example and add the bootloader. The PRM file for this project required some modifications. Below is the text used for the new PRM file for this example with the bootloader. This file is located at the following path under the CMX Installation root directory:

\usb-peripheral\projects\CodeWarrior\hc9S08jm60\hid-demo\prm\Project.prm

```
/*******************
                         (c) copyright Freescale Semiconductor 2008
  ALL RIGHTS RESERVED
  File Name: Project.prm
*
*
  Purpose: This file is for a USB Mass-Storage Device bootloader. This file
*
           is the Linker Command File for the bootloader, and defines the
          memory locations for both bootloader and application code
*
  Assembler: Codewarrior for Microcontrollers V6.2
  Version: 1.2
  Author: Derek Snell
  Location: Indianapolis, IN. USA
4
*
 UPDATED HISTORY:
* REV
       YYYY.MM.DD AUTHOR
                              DESCRIPTION OF CHANGE
 ___
       _____ ____
                               _____
       2009.01.12 Derek Snell
* 1.2
                             Ported to SO8 from V1
 1.1
       2008.10.09 Derek Snell
                               Overlapped RAM of Bootloader and Application
* 1.0
       2008.06.10 Derek Snell
                              Initial version
/* Freescale is not obligated to provide any support, upgrades or new */
/* releases of the Software. Freescale may make changes to the Software at */
/* any time, without any obligation to notify or provide updated versions of */
/* the Software to you. Freescale expressly disclaims any warranty for the */
/* Software. The Software is provided as is, without warranty of any kind, */
/* either express or implied, including, without limitation, the implied */
/* warranties of merchantability, fitness for a particular purpose, or */
/* non-infringement. You assume the entire risk arising out of the use or */
/* performance of the Software, or any systems you design using the software */
/* (if any). Nothing may be construed as a warranty or representation by */
/* Freescale that the Software or any derivative work developed with or */
/* incorporating the Software will be free from infringement of the */
/* intellectual property rights of third parties. In no event will Freescale */
/* be liable, whether in contract, tort, or otherwise, for any incidental, */
/* special, indirect, consequential or punitive damages, including, but not */
/* limited to, damages for any loss of use, loss of time, inconvenience, */
/* commercial loss, or lost profits, savings, or revenues to the full extent */
```



PRM File for the MC9S08 CMX Example

/* such may be disclaimed by law. The Software is not fault tolerant and is */ /* not designed, manufactured or intended by Freescale for incorporation *//* into products intended for use or resale in on-line control equipment in */ /* hazardous, dangerous to life or potentially life-threatening environments */ /* requiring fail-safe performance, such as in the operation of nuclear */ /* facilities, aircraft navigation or communication systems, air traffic */ /* control, direct life support machines or weapons systems, in which the */ /* failure of products could lead directly to death, personal injury or */ /* severe physical or environmental damage (High Risk Activities). You *//* specifically represent and warrant that you will not use the Software or */ /* any derivative work of the Software for High Risk Activities. */ /* Freescale and the Freescale logos are registered trademarks of Freescale */ /* Semiconductor Inc. * / /* This is a linker parameter file for the mc9s08jm60 */ NAMES END /* CodeWarrior will pass all the needed files to the linker by command line. But here you may add your own files too. */ HEXFILE S08 Bootloader.abs.s19 SEGMENTS /* Here all RAM/ROM areas of the device are listed. Used in PLACEMENT below. */ // Bootloader Segments Bootloader = READ ONLY 0xEC00 TO 0xFFAD; Bootloader RAM = READ WRITE 0x0100 TO 0x105F; Bootloader USB RAM = READ WRITE 0x1860 TO 0x195F; /* INTVECTS = READ ONLY 0xFFC4 TO 0xFFFF; Reserved for Interrupt Vectors */ // Application Segments = READ ONLY 0x1960 TO 0xEBA5; ROM = READ WRITE Z RAM 0x00B0 TO 0x00FF; Application RAM = READ WRITE 0x0100 TO 0x101F; Application USB RAM = READ WRITE 0x1860 TO 0x195F; ROM1 = READ ONLY 0x10B0 TO 0x17FF; ROM2 = READ ONLY 0xFFC0 TO 0xFFC3; MY STACK = READ WRITE 0x1020 TO 0x10AF; END PLACEMENT /* Here all predefined and user segments are placed into the SEGMENTS defined above. */ DEFAULT RAM INTO Application RAM, Application USB RAM; PRESTART, 11 /* startup code */ .init, /* startup data structures */ STARTUP, ROM VAR, /* constant variables */ STRINGS, /* string literals */ VIRTUAL TABLE SEGMENT, /* C++ virtual table segment */ DEFAULT ROM, COPY /* copy down information: how to initialize variables */



PRM File for the MC9S08 CMX Example

_DATA_ZEROPAGE,	MY_ZEROPAGE	INTO	Z_RAM;
SSTACK		INTO	MY_STACK;

END

STACKTOP 0x10AF



Appendix H hid_main.c for the MC9S08 CMX Example

Section 4.6, "Adding the Bootloader to the Existing MC9S08 Project," on page 36 gives detailed steps to start with the MC9S08 CMX Example and add the bootloader. The hid_main.c file for this project required several modifications. Below is the text used for the new hid_main.c file for this example with the bootloader. This file is located at the following path under the CMX Installation root directory:

```
\usb-peripheral\src\hc9s08\hid-demo\hid main.c
```

```
Copyright (c) 2006-2007 by CMX Systems, Inc.
 This software is copyrighted by and is the sole property of
* CMX. All rights, title, ownership, or other interests
* in the software remain the property of CMX. This
* software may only be used in accordance with the corresponding
* license agreement. Any unauthorized use, duplication, transmission,
* distribution, or disclosure of this software is expressly forbidden.
* This Copyright notice may not be removed or modified without prior
* written consent of CMX.
* CMX reserves the right to modify this software without notice.
* CMX Systems, Inc.
* 12276 San Jose Blvd. #511
* Jacksonville, FL 32223
* USA
* Tel: (904) 880-1840
* Fax: (904) 880-1632
* http: www.cmx.com
* email: cmx@cmx.com
#include "usb-drv/usb.h"
#include "target.h"
#include "hid mouse.h"
#include "hid kbd.h"
#include "hid generic.h"
/* none */
*****
/* none */
/* none */
```

NP

hid_main.c for the MC9S08 CMX Example

```
/* none */
// Added for Bootloader
 #include "Bootloader S08.h"
 void _Startup(void);
 // User Application code entry
 volatile const JumpVect UsrEntry@ USER ENTRY ADDRESS = {
   0xCC,
          // op-code for JMP
   _Startup
 };
 interrupt void Dummy ISR(void) {}
 // User Interrupt Jump Vector Table
 volatile const JumpVect UserJumpVectors [InterruptVectorsNum] @ VectorAddressTableAddress = {
     { 0xCC, Dummy_ISR},
                       // 29 - RTC
    { 0xCC, Dummy_ISR},
                       // 28 - IIC
    { 0xCC, Dummy_ISR},
                      // 27 - ACMP
                      // 26 - ADC Conversion
    { 0xCC, Dummy ISR},
    { 0xCC, Dummy ISR},
                      // 25 - KBI
    { 0xCC, Dummy ISR},
                      // 24 - SCI2 Transmit
                      // 23 - SCI2 Receive
    { 0xCC, Dummy ISR},
    { 0xCC, Dummy_ISR},
                      // 22 - SCI2 Error
    { 0xCC, Dummy ISR},
                      // 21 - SCI1 Transmit
    { 0xCC, Dummy ISR},
                       // 20 - SCI1 Receive
                       // 19 - SCI1 Error
    { 0xCC, Dummy ISR},
    { 0xCC, Dummy_ISR},
                       // 18 - TPM2 Overflow
    { 0xCC, Dummy_ISR},
                       // 17 - TPM2 Channel1
    { 0xCC, Dummy_ISR},
                      // 16 - TPM2 Channel0
                     // 15 - TPM1 Overflow
    { 0xCC, Dummy ISR},
    { 0xCC, Dummy ISR},
                     // 14 - TPM1 Channel5
    { 0xCC, Dummy ISR},
                     // 13 - TPM1 Channel4
    { 0xCC, Dummy ISR},
                     // 12 - TPM1 Channel3
    { 0xCC, Dummy ISR},
                      // 11 - TPM1 Channel2
    { 0xCC, Dummy_ISR},
                      // 10 - TPM1 Channel1
    { 0xCC, Dummy ISR},
                       // 9 - TPM1 Channel0
                      // 8 - Reserved
    { 0xCC, Dummy ISR},
    { 0xCC, usb_it_handler}, // 7 - USB Status
    { 0xCC, Dummy_ISR},
                       // 6 - SPI2
    { 0xCC, Dummy_ISR},
                       // 5 - SPI1
    { 0xCC, Dummy_ISR},
                       // 4 - MCG Loss Lock
    { 0xCC, Dummy_ISR},
                      // 3 - Low VoltDetect
                      // 2 - IRQ
    { 0xCC, Dummy ISR},
    { 0xCC, Dummy ISR},
                       // 1 - SWI
 };
int main()
{
 hcc u8 tmp;
```



```
NP
```

```
hw_init();
 /* See in what mode should we run. */
 tmp = (hcc u8) (SW1 ACTIVE() ? 1 : 0);
 tmp |= (hcc_u8)(SW2_ACTIVE() ? 2 : 0);
 /* Start the right HID application. */
 switch(tmp)
 {
 default:
 case 0:
   usb_cfg_init();
   set_mode(dm_mouse);
   (void)hid mouse();
   break;
 case 1:
   usb_cfg_init();
   set_mode(dm_kbd);
   hid_kbd();
   break;
 case 2:
   usb_cfg_init();
   set_mode(dm_generic);
   hid_generic();
   break;
 }
 /* We will never get here. */
 return 0;
}
  /
```



How to Reach Us:

Home Page: www.freescale.com

Web Support:

http://www.freescale.com/support

USA/Europe or Locations Not Listed:

Freescale Semiconductor, Inc. Technical Information Center, EL516 2100 East Elliot Road Tempe, Arizona 85284 +1-800-521-6274 or +1-480-768-2130 www.freescale.com/support

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH Technical Information Center Schatzbogen 7 81829 Muenchen, Germany +44 1296 380 456 (English) +46 8 52200080 (English) +49 89 92103 559 (German) +33 1 69 35 48 48 (French) www.freescale.com/support

Japan:

Freescale Semiconductor Japan Ltd. Headquarters ARCO Tower 15F 1-8-1, Shimo-Meguro, Meguro-ku, Tokyo 153-0064 Japan 0120 191014 or +81 3 5437 9125 support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor China Ltd. Exchange Building 23F No. 118 Jianguo Road Chaoyang District Beijing 100022 China +86 10 5879 8000 support.asia@freescale.com

For Literature Requests Only: Freescale Semiconductor Literature Distribution Center 1-800-441-2447 or 303-675-2140 Fax: 303-675-2150 LDCForFreescaleSemiconductor@hibbertgroup.com

Document Number: AN3927 Rev. 1 02/2012 Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.

RoHS-compliant and/or Pb-free versions of Freescale products have the functionality and electrical characteristics as their non-RoHS-compliant and/or non-Pb-free counterparts. For further information, see http://www.freescale.com or contact your Freescale sales representative.

For information on Freescale's Environmental Products program, go to http://www.freescale.com/epp.

Freescale[™] and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. © Freescale Semiconductor, Inc. 2009, 2012. All rights reserved.

