

Electrode Graphing Tool IIC Driver Errata

by: Microcontroller Division

This errata document describes corrections to the *Electrode Graphing Tool IIC Driver*. For convenience, the addenda items are grouped by revision. Please check our website at <http://www.freescale.com/touchsensing> for the latest updates.

The current version available of the *Touch Sensing Library* is Revision 1.1.

The current version available of the *Electrode Graphing Tool* is Revision 0.9

Table of Contents

1	Errata for Revision 2	2
2	Errata for Revision 1.1	5
3	Revision History	8

1 Errata for Revision 0.9

Table 1. Electrode Graphing Tool Rev 2.0 Errata

Location	Description
TSS library version 1.1	New IIC drivers were included in the examples to correctly write to the sensitivity values for electrodes E16-E63.
Electrode Graphing Tool	New IIC Communications protocol to enable modifications to electrodes E16-E63.
JM Comm Firmware	Modified IIC Communication Protocol between EGT AND target MCU

2 Workaround

To modify the sensitivity of the electrodes 17-64 it is necessary to have installed TSS library version 1.1 or later, Electrode Graphing Tool version 0.9 or later, and the JM60Comm firmware version 1.3 or later programmed on the JM60 Comm MCU. All these files can be found at www.freescale.com. The following points give the specific steps necessary to enable the workaround.

2.1 TSS Library update

The TSS library files are distributed in the form of binary library and source code for compile time configuration and optimization. To install the TSS on your host PC:

1. Download the latest version of the TSS setup file form [Freescale website](http://www.freescale.com).
2. Run the self-extracting setup executable and follow the on-screen instructions.
3. When the system prompts for the destination folder, accept the default value or provide another path.
4. The application project using the TSS library makes only a reference to the TSS files. You can copy the library files into the application project directory or leave them in the installation folder. Leaving the library files in the installation folder enables you in the future to upgrade your project to the newer TSS library versions.

2.2 Replacing I2CDrv.c and I2CDrv.h Files in a Project

If you already have a project that is using the I2CDrv.c and I2CDrv.h files, you will have to replace the files with those in the TSS Library. These files can be found on your computer once the TSS Library 1.1 or later is installed within the TSS Library folder:

C:\Program Files\Freescale\Freescale TSS 1.1\examples\TSSEVB_DEMO\Sources\EGT\

2.3 Electrode Graphing Tool Installation

The Electrode Graphing Tool (EGT) version 0.9 must also be installed. To install the EGT, perform the following steps:


1. Get the latest version of the EGT on the Freescale web site at www.freescale.com.
2. Unzip the EGTInstaller.zip file to a local folder on your computer.

3. Launch the Electrode Graphing Tool installer EGTInstaller.msi. The **Wizard Installer** window appears. Click **Next** to begin the installation process.
4. The **Select Installation Folder** window then appears as shown in Figure3-2. Choose a destination folder or leave the default destination path. Select if the application will be available for all users on the computer or only for the current user (administrator privileges are needed to make an installation for all users). The **Disk Cost** button shows the free space on your local drive and gives information about how much disk space the application will require. Click **Next** to continue.
5. The **Confirm Installation** window appears. Click **Next** to start copying the files onto your computer. A window indicating the installation progress will then appear. After installation, a window indicating that the installation is completed appears. Click the **Close** button.


2.4 JM60 Comm Firmware Update

Lastly, it is necessary to update the JM60 Comm MCU that can be found on the TSSEVB. To do this, it is necessary to:

1. Download the latest version of the JM60 Comm Firmware from the [Freescale website](#).
2. Open the .mcp Project using CodeWarrior.
3. Set the MC9S08JM60 Comm MCU as a programming target on the TSSEVB. To do this, place the jumpers of the J6 to the 1–3 and 2–4 position, as pictured here:



4. Power on the TSSEVB through a USB cable through the OSBBDM (J8) connector.
5. Set power selection of the TSSEVB to use OSBDM source



6. After the TSSEVB is powered up, the user can reprogram the JM60 Comm MCU with the new firmware using CodeWarrior and the True Time Simulator and Debugger.

3 Revision History

Table 2. Revision History Table

Rev. Number	Substantive Changes	Date of Release
0.8	Initial release.	09/2009
0.9	Second release. Updated IIC driver to modify electrode sensitivity values for electrodes E16-E63.	02/2010



How to Reach Us:

Home Page:

www.freescale.com

E-mail:

support@freescale.com

USA/Europe or Locations Not Listed:

Freescale Semiconductor
Technical Information Center, CH370
1300 N. Alma School Road
Chandler, Arizona 85224
+1-800-521-6274 or +1-480-768-2130
support@freescale.com

Europe, Middle East, and Africa:

Freescale Halbleiter Deutschland GmbH
Technical Information Center
Schatzbogen 7
81829 Muenchen, Germany
+44 1296 380 456 (English)
+46 8 52200080 (English)
+49 89 92103 559 (German)
+33 1 69 35 48 48 (French)
support@freescale.com

Japan:

Freescale Semiconductor Japan Ltd.
Headquarters
ARCO Tower 15F
1-8-1, Shimo-Meguro, Meguro-ku,
Tokyo 153-0064, Japan
0120 191014 or +81 3 5437 9125
support.japan@freescale.com

Asia/Pacific:

Freescale Semiconductor Hong Kong Ltd.
Technical Information Center
2 Dai King Street
Tai Po Industrial Estate
Tai Po, N.T., Hong Kong
+800 2666 8080
support.asia@freescale.com

For Literature Requests Only:

Freescale Semiconductor Literature Distribution Center
P.O. Box 5405
Denver, Colorado 80217
1-800-441-2447 or 303-675-2140
Fax: 303-675-2150
LDCForFreescaleSemiconductor@hibbertgroup.com

Information in this document is provided solely to enable system and software implementers to use Freescale Semiconductor products. There are no express or implied copyright licenses granted hereunder to design or fabricate any integrated circuits or integrated circuits based on the information in this document.

Freescale Semiconductor reserves the right to make changes without further notice to any products herein. Freescale Semiconductor makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does Freescale Semiconductor assume any liability arising out of the application or use of any product or circuit, and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters that may be provided in Freescale Semiconductor data sheets and/or specifications can and do vary in different applications and actual performance may vary over time. All operating parameters, including "Typicals", must be validated for each customer application by customer's technical experts. Freescale Semiconductor does not convey any license under its patent rights nor the rights of others. Freescale Semiconductor products are not designed, intended, or authorized for use as components in systems intended for surgical implant into the body, or other applications intended to support or sustain life, or for any other application in which the failure of the Freescale Semiconductor product could create a situation where personal injury or death may occur. Should Buyer purchase or use Freescale Semiconductor products for any such unintended or unauthorized application, Buyer shall indemnify and hold Freescale Semiconductor and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if such claim alleges that Freescale Semiconductor was negligent regarding the design or manufacture of the part.



Freescale™ and the Freescale logo are trademarks of Freescale Semiconductor, Inc. All other product or service names are the property of their respective owners. © Freescale Semiconductor, Inc. 2007. All rights reserved.

TSSEGTUGAD
Rev. 1
03/2010